

Manual Page	Part Number	Description	SVF 750	SVF 1000	SVF 1100
105	384000143	Annual Maintenance Kit	●	●	●
	384000146	Kit-Service, Gasket-Seal	●		
	384000147	Kit-Service, Gasket-Seal		●	●
108	384000111	Kit-Service, Blower Modulating RG175	●		
	384000112	Kit-Service, Blower Modulating GIG170		●	●
	384000113	Kit-Service, Venturi Honeywell VMU 300A	●		
	384000114	Kit-Service, Venturi Honeywell VMU 335A		●	●
	384000116	Kit-Service, Valve-Gas Honeywell VR4730C w/ Hardware	●		
	384000117	Kit-Service, Valve-Gas Honeywell VR4734C w/ Hardware		●	●
110	384000103	Ignitor / Flame Sense Rod Kit (<i>Ignitor, Flame Sense, Gasket, Hardware, Ground Harness</i>)	●	●	●
	384000100	Temp Sensor, Flue & Water	●	●	●
	383600511	Low Water Cut-Off	●	●	●
	384000104	Kit, Pressure Switch (<i>Pressure Switch, Min Air Flow Switch, Hoses, Hardware</i>)	●		
	384000105	Kit, Pressure Switch (<i>Pressure Switch, Min Air Flow Switch, Hoses, Hardware</i>)		●	●
	510312218	Sensor, Outdoor Temperature	●	●	●
	384000102	Expansion Module 120 Volt	●	●	●
	384000000	Control Module Kit (<i>Module, Hardware</i>)	●	●	●
	383500628	Control Transformer, 120/24VAC	●	●	●
	570350231	Blower Relay (<i>w/out Socket</i>)	●	●	●
	511802626	Ignition Transformer	●	●	●
	383500603	Fuse, 3-Amp Fast Blow ATO (<i>5 Fuses</i>)	●	●	●
	383500604	Fuse, 12-Amp 250-Volt Fast Blow AG (<i>5 Fuses</i>)	●	●	●