



FIELD WIRING — — — —
 FACTORY WIRING — — — —
 ③ CONTROL RELAY TERMINAL
 ④ CONTROL PANEL TERMINAL

*Not required for factory mutual specifications.

- NOTES: 1. Left End Gas Train used for all F.I.A. and F.M. Specifications.
 2. Right End Gas Train only used for F.I.A. and F.M. Specifications according to following schedule.
- For F.I.A. Specifications, applicable to MG-26 through MG-38 boilers ordered for 5.0" W.C. gas pressure and for MG-29 through MG-38 boilers ordered for 7.0" W.C. gas pressure.
 - For F.M. Specifications, applicable to MG-28 through MG-38 boilers ordered for 5.0" W.C. gas pressure, and for MG-34 through MG-38 boilers ordered for 7.0" W.C. gas pressure.