



Gas-fired water boilers - Series 3



Quick-Reference Guide

For Piping, Wiring & U-Control Setups



AWARNING

This guide must only be used by a qualified heating installer/service technician. Read all instructions, including this Ultra boiler manual and all other information shipped with the boiler, before installing. Perform steps in the order given. Failure to comply could result in severe personal injury, death or substantial property damage.

WM

Read before proceeding





Contents

General piping requirements	Application 13 Single-zone BASE
Weil-McLain Easy-Up® Manifold	Application 14
Factory-built manifolds including near-boiler piping and system sec- ondary connection	Multi-zone BASEB valves) DHW (Di
U-Control Screens	total heat loss)
U-Control menu access	Application 15 Single-zone BASE
Application 1	Application 16
Application 2	Single or Multi-zone ISOLATION Heat e system operating p
Application 3	Multiple boiler o
Application 4	Using the U-Contro
DHW (As zone in system)	ALTERNATIVE Hea
Multi-zone RADIANT DHW (Direct-connected) HEAT EXCHANGER (WMBP or WMPH) (<30% of total heat loss)	Application 17a
Application 6	NON-HYDRONIC F as Type 2 (BACKUI FAN COIL DHV
Application 7	Application 18 -
Multiple HI-TEMP HEATING zones DHW (Direct-connected) Small RADIANT zone (<30 of total heat loss)	Multiple Ultra boiler with WMCR) DH
Application 7a	Application 19 -
radiant or hi-temp space heating circuits)	Multiple Ultra boiler DHW (In system) (6
Application 8	Application 20 -
DHW (Direct-connected)	Multiple Ultra boiler (Direct-connected)
Application 9	Application 21 -
DHW (Direct-connected)	BASE LOADING w
Application 10	Appendix A
Application 11	Appendix B.
Application 12	Appendix C.

pplication 13
ingle-zone BASEBOARD DHW (System, as zone)
pplication 14
lulti-zone BASEBOARD (Zone valves) Multi-zone RADIANT (Zone alves) DHW (Direct-connected) (Radiant load must be <30% of otal heat loss)
pplication 15
ingle-zone BASEBOARD Single-zone RADIANT POOL Heat xchanger (Radiant load must be <30% of total heat loss)
pplication 16
ingle or Multi-zone SPACE HEATING DHW (Direct-connected) SOLATION Heat exchanger (Tall buildings) (Use where space heating ystem operating pressure is over 25 PSIG)
Iultiple boiler operation options
sing the U-Control settings
pplication 17 — Multiple heat sources
LTERNATIVE Heat source as primary / ULTRA as back-up ingle-zone BASEBOARD or FAN COIL — DHW (Direct-connected)
pplication 17a — Multiple heat sources
ON-HYDRONIC PRIMARY Heat source as Type 1 (LEAD) / ULTRA s Type 2 (BACKUP) — Single-zone or multi-zone BASEBOARD or AN COIL DHW (Direct-connected)
pplication 18 — Multiple boilers
lultiple Ultra boilers Multiple-zone SPACE HEATING (Circulators ith WMCR) DHW (Direct-connected)
pplication 19 — Multiple boilers
Iultiple Ultra boilers Multi-zone SPACE HEATING & HW (In system) (Circulators with WMCR controllers)
pplication 20 — Multiple boilers
lultiple Ultra boilers Multiple loads on SECONDARY loops DHW Direct-connected)
pplication 21 — Multiple boilers
ASE LOADING with ULTRA boilers DHW (Direct connected)
Appendix A.
Appendix B
UILER SETTINGS MENU detail
Appendix C. . <td< td=""></td<>



General piping requirements

The Ultra boiler must ALWAYS be piped in a secondary loop off of the primary loop



The circulator supplied with the boiler (a) must be used only in the boiler secondary loop as shown in the schematic above and in the manual. System (b) and zone circulators and DHW circulator (c) must be supplied by the installer. Above right is a typical installation, showing the near-boiler piping and connection to the system. Boiler loop piping must be sized to the minimums listed in the boiler manual. Using smaller piping will cause performance problems.

- + Ultra-80 / Ultra-105. use 1" or larger
- Ultra-155 / Ultra-230. use 1¹/₄" or larger
- + Ultra-299 / Ultra-399. use $1^{1\!/\!2}$ or larger



INSTALLING THE PRIMARY/SECONDARY TEES

The near-boiler piping must be primary/secondary as shown above and left, with the boiler loop piping entering the tees in the branch connection.

DO NOT connect boiler piping to the tee through connections as shown at right. The system will not work correctly this way.





Weil-McLain Easy-Up® Manifold

Factory-built manifolds including near-boiler piping and system secondary connection





U-Control Screens

NOTICE

See individual application instructions for required and optional control settings using the BOILER SETTINGS and SYSTEM SETTINGS menus. See Appendices for additional menu details.





U-Control menu access

BOILER SETTINGS | SYSTEM SETTINGS



See individual application instructions for required and optional control settings using the BOILER SETTINGS and SYSTEM SETTINGS menus. See Appendices for additional menu details.





Single-zone BASEBOARD | DHW (Direct-connected)

Purpose

- Space heating with finned tube or cast iron baseboard, plus DHW supplied by a single boiler.
- DHW priority space heating is disabled during call for heat from water heater.

U-Control settings

- See the table at right for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.
- Select DHW DIRECT for the DHW BOILER PRIORITY 1. This informs the control that the DHW tank is directly connected to the boiler.

Circulators and piping

• Piping must be primary/secondary as shown, with the boiler piped in a secondary loop and the DHW piped to the boiler loop.

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping — see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently see boiler manual and other applications in this guide.
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

BASEBOARD system

- Size for required flow.
- System circulator supplied by installer.
- Single zone only (see other applications in this guide for zoning)
- Piping can be one-pipe or two-pipe (provide balancing valves if needed).
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

BOILER

- · Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

- Connect field wiring as shown on next page.
- This application applies only to single-zone space heating see other applications in this guide for multiple-zone systems.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each if load is higher, provide a circulator relay or contactor for circulator power.

-CONTROL	SETTINGS
SEE NAVIGATION E	

- VALUE MUST BE SET (OR VERIFIED) AS INDICATED DEFAULT ACCEPTABLE; CHANGE ONLY IF DESIRED

BOILER SETTINGS

BOILER MODEL	Verify model number is correct	
HIGH ALTITUDE	Set to YES if high altitude	
HIGH LIMIT	D	
WWSD TEMP	DEFAULT (70 °F) OR AS REQUIRED	
ADJUST OUTDOOR	DEFAULT (0 °F) OR AS REQUIRED	
ADD'L HEAT DEMAND TYPE	D	
ADD'L HEAT DEMAND TIME	D	
SYSTEM SETTINGS		

	SYSTEM TYPE	Select from list	DHW DIRECT
		Max Supply	190 F
	TEMPERATURES	Max OD Reset	D
	TEMP ENATONES	Min OD Reset	D
		Modulate On Diff	
BOILER PRIORITY 1		Max On Time	D
	TIMES	Boost Interval	D
		Prepump Time:	D
		Postpump Time:	D
		Circulator 1	ON
	CIRCULATORS	Circulator 2	OFF
	MAXIMUM RATE	on culator 5	D
	MINIMUM RATE		D
	SYSTEM TYPE	Select from list	FTB or CIB
		Max Supply	180 F
		Min Supply	D
	TEMPERATURES	Max OD Reset	D (70F) or as req'd
		MIN OD Reset Modulate On Diff	D (UF) or as req d
		Modulate Off Diff	D
		Max On Time	D
Bacoboard		Min On Time	D
	TIMES	Boost Interval	D
(Finned tube or cast iron)		Postpump Time:	D
		Circulator 1	OFF
	CIRCULATORS	Circulator 2	ON
		Circulator 3	ON
			D
\/		Select from list	D
\backslash /	STOTEMTTE	Max Supply	D
\backslash		Min Supply	D
	TEMPERATURES	Max OD Reset	D
		Min OD Reset	D
		Modulate Off Diff	D
BOILER PRIØRITY 3			
X		Min On Time	D
Not used	TIMES	Boost Interval	D
		Prepump Time: Postpump Time:	D
		Circulator 1	D
	CIRCULATORS	Circulator 2	D
		Circulator 3	D
	MAXIMUM RATE		D
/			D
CIDCIII ATAD EVEDCICING	Circulator 1		D
υπουίαι υπ ελεποιδίΝα	Circulator 3		D
	Circulator 1		D
FREEZE PROTECT CIRCS	Circulator 2		D
	Circulator 3		D



LEGEND

J.

***** = Supplied by installer

- 1 DHW circulator *
- 2 BOILER circulator (shipped loose with boiler)
 - SYSTEM circulator *
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control

3

8

- 6 House thermostat *
- 7 Supply temperature sensor strap to supply line
 - Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- **10** Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- 21 Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves '
- 24 Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- **26** Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)





Single-zone FAN COIL(S) | DHW (Direct-connected)

Purpose

- Space heating with fan coil(s) and DHW supplied by a single boiler.
- DHW priority space heating is disabled during call for heat from water heater.

U-Control settings

- See the table at right for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.
- Select DHW DIRECT for the DHW BOILER PRIORITY 1. This informs the control that the DHW tank is directly connected to the boiler.

Circulators and piping

Piping must be primary/secondary as shown, with the boiler piped in a secondary loop and the DHW piped to the boiler loop.

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping - see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently - see boiler manual and other applications in this guide.
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

FAN COIL system

- Size for required flow.
- System circulator supplied by installer.
- Single zone only (see other applications in this guide for zoning)
- Piping can be one-pipe or two-pipe (provide balancing valves if needed).
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

BOILER

- See boiler manual for sizing.
- Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

- Connect field wiring as shown on next page.
- This application applies only to single-zone space heating see other applications in this guide for multiple-zone systems.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each — if load is higher, provide a circulator relay or contactor for circulator power.

U-CONTROL SET (SEE NAVIGATION FLOW BE	TTINGS XXX ELOW)	— VALUE MUST BE SET (C — DEFAULT ACCEPTABLE; (R VERIFIED) AS INDICATEI CHANGE ONLY IF DESIRED
	BOILER SE	TTINGS	
		Verify model nu	mber is correct
		Set to YES if	high altitude
HIGH LIMIT		[)
WWSD TEMP		DEFAULT (70 °F)	OR AS REQUIRED
ADJUST OUTDOOR		DEFAULT (0 °F)	OR AS REQUIRED
ADD'L HEAT DEMAND TYPE		[)
ADD'L HEAT DEMAND TIME		0)
	SYSTEM SE	TTINGS	
	SYSTEM TYPE	Select from list	DHW DIRECT
		Max Supply	190 F
	TEMPERATURES	Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D
BOILER PRIORITY 1		Max On Time	D
DHW	TIMES	Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	ON OFF OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
	TEMPERATURES	Select from list Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	FCL 190 F D D (70F) or as req'd D (0F) or as req'd D D
<i>BOILER PRIORITY 2</i> Fan coils	TIMES	Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON ON
	MAXIMUM RATE		D
\		Select from list	D
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D D D
BOILER PRIØRITY 3 Not used	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D

D

D

D

D

D

D

D

D

D

Circulator 1

Circulator 2

Circulator 3

CIRCULATORS

MAXIMUM RATE

MINIMUM RATE Circulator 1

Circulator 2

Circulator 3

Circulator 1

Circulator 2

Circulator 3

CIRCULATOR EXERCISING

FREEZE PROTECT CIRCS



LEGEND

I

***** = Supplied by installer

- 1 DHW circulator *
- 2 BOILER circulator (shipped loose with boiler)
 - SYSTEM circulator *
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control

3

8

- 6 House thermostat *
- 7 Supply temperature sensor strap to supply line
 - Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- **10** Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- 21 Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves '
- 24 Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- **26** Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)







Single-zone CAST IRON RADIATORS | DHW (Direct-connected)

U

Purpose

- Space heating with cast iron radiators and DHW supplied by a single boiler.
- DHW priority space heating is disabled during call for heat from water heater.

U-Control settings

- See the table at right for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.
- Select DHW DIRECT for the DHW BOILER PRIORITY 1. This informs the control that the DHW tank is directly connected to the boiler.

Circulators and piping

• Piping must be primary/secondary as shown, with the boiler piped in a secondary loop and the DHW piped to the boiler loop.

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping — see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently see boiler manual and other applications in this guide.
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

RADIATOR system

- Size for required flow.
- System circulator supplied by installer.
- Single zone only (see other applications in this guide for zoning)
- Piping can be one-pipe or two-pipe (provide balancing valves if needed).
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

BOILER

- See boiler manual for sizing.
- Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

- Connect field wiring as shown on next page.
- This application applies only to single-zone space heating see other applications in this guide for multiple-zone systems.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each if load is higher, provide a circulator relay or contactor for circulator power.

-Contre	OL SE	ETTI	IGS
(SEE NAVIGAT	ION FLOW	BELOW)

VALUE MUST BE SET (OR VERIFIED) AS INDICATED
 DEFAULT ACCEPTABLE; CHANGE ONLY IF DESIRED

BOILER SETTINGS

Verify model number is correct		
Set to YES if high altitude		
D		
DEFAULT (70 °F) OR AS REQUIRED		
DEFAULT (0 °F) OR AS REQUIRED		
D		
D		
SYSTEM SETTINGS		

	SYSTEM TYPE	Select from list	DHW DIRECT
		Max Supply Max OD Reset	190 F D
	TEMPERATURES	Min OD Reset Modulate On Diff Modulate Off Diff	D D D
BOILER PRIORITY 1		Max On Time	D
DHW	TIMES	Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	ON OFF OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
	SYSTEM TYPE	Select from list	CIR
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate Off Diff	180 F D D (70F) or as req'd D (0F) or as req'd D
<i>BOILER PRIORITY 2</i> Radiators	TIMES	Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON ON
	MAXIMUM RATE		D
	MINIMUM RATE		D
\ /	SYSTEM TYPE	Select from list	D
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D D
BOILER PRIORITY 3	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
	MAXIMUM RATE		D
/ \	MINIMUM RATE		D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		D D D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3		D D D



LEGEND

I

\star = Supplied by installer

- 1 DHW circulator *
- 2 BOILER circulator (shipped loose with boiler)
- 3 SYSTEM circulator *
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control

8

- 6 House thermostat *
- 7 Supply temperature sensor strap to supply line
 - Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- **10** Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- 21 Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves '
- 24 Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- **26** Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)







Multi-zone SPACE HEATING (Circulators + WMCR) | DHW (As zone in system)

Purpose

- Space heating with multiple zones. This system is applicable to any terminal unit type, including radiant.
- Zoning with circulators.
- DHW piped as a separate zone.
- DHW priority space heating is disabled during call for heat from water heater.

U-Control settings

- See the table at right for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.
- Select DHW SYSTEM for the DHW BOILER PRIORITY 1. This informs the control that the DHW tank is a system zone, not directly connected to the boiler.

Circulators and piping

• Piping must be primary/secondary as shown.

DHW

- DHW circulator must be sized for required flow and head loss.
- DHW circulator supplied by installer.
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

SPACE HEATING

- Mutliple zones
- Size circulators for required flow.
- Space heating circulators supplied by installer.
- Circulators controlled by Weil-McLain WMCR controller.

BOILER

- See boiler manual for sizing.Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

- Connect field wiring as shown on next page.
- This application applies only to multiple-zone space heating, using Weil-McLain zone controller.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each if load is higher, provide a circulator relay or contactor for circulator power.

-CONTROL SET	TINGS	
(SEE NAVIGATION FLOW BE	LOW)	

VALUE MUST BE SET (OR VERIFIED) AS INDICATED
 DEFAULT ACCEPTABLE; CHANGE ONLY IF DESIRED

BOILER SETTINGS

BOILER MODEL		Verify model number is correct	
HIGH ALTITUDE		Set to YES if high altitude	
HIGH LIMIT		0)
WWSD TEMP		DEFAULT (70 °F) OR AS REQUIRED	
ADJUST OUTDOOR		DEFAULT (0 °F) OR AS REQUIRED	
ADD'L HEAT DEMAND TYPE	E	D	
ADD'L HEAT DEMAND TIME		D	
	SYSTEM SE	TTINGS	
	SYSTEM TYPE	Select from list	DHW SYSTEM

	SYSTEM TYPE	Select from list	DHW SYSTEM
		Max Supply	190 F
	TEMPERATURES	Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D
BOILER PRIORITY 1		Max On Time	D
DHW	TIMES	Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	ON ON OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
	SYSTEM TYPE	Select from list	Select type used
BOILER PRIORITY 2	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	As req'd D D (70F) or as req'd D (0F) or as req'd D D
Space heating (any type)	TIMES	Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
\backslash /	SYSTEM TYPE	Select from list	D
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D D
BOILER PRIORITY 3 Not used	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
	MAXIMUM RATE		D
/ \	MINIMUM RATE		D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		D D D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3		D D D



LEGEND

M

***** = Supplied by installer

- 1 DHW circulator *
- 2 BOILER circulator (shipped loose with boiler)
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- 6 Space heating zone thermostats *
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- 10 Outdoor temperature sensor
- **11** Low water cutoff (if used) *
- 12 Circulator zone controller, Weil-McLain WMCR select for number of zones required *
- 16 Space heating zone circulators *
- 22 Indirect water heater •
- 23 Flow/check valves *
- 24 Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- 26 Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)





Multi-zone RADIANT | DHW (Direct-connected) | HEAT EXCHANGER (WMBP or WMPH) (<30% of total heat loss)

Purpose

- Space heating with multiple radiant zones (zone valve zoning).
- Heat exchanger, brazed plate (WMBP) or pool heater (WMPH) in separate zone. Heating load must be less than 30% of total heat loss. Alternatively, see Application 7a, which does not limit load sizes.
- DHW piped directly to the boiler.
- DHW priority space heating and heat exchanger heating are disabled during call for heat from water heater.

U-Control setting notes

- See the table at right for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.
- Select DHW DIRECT for the DHW BOILER PRIORITY 1. This informs the control that the DHW tank is directly connected to the boiler.
- Select SYSTEM TYPE DHW for BOILER PRIORITY 3, the heat exchanger circuit. This prevents outdoor reset regulation of supply temperature during heat exchanger operation.

Circulators and piping

• Piping must be primary/secondary as shown.

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently see boiler manual and other applications in this guide.
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

RADIANT

- Size circulators for required flow.
- Radiant circulators supplied by installer.

NOTICE

See **Application 7a**, page 22, for radiant heating using independent temperature control for the radiant zone.

HEAT EXCHANGER

- Heat exchanger load must be less than 30% of total heat loss.Size circulator for required flow.
- Typical application shown using Weil-McLain brazed plate (WMBP) exchanger or pool heater (WMBP).
- Heat exchanger and circulator supplied by installer.

BOILER

- See boiler manual for sizing.
- Circulator shipped loose with boiler.
 Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

- Connect field wiring as shown on next page.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each if load is higher, provide a circulator relay or contactor for circulator power.
- Provide WMR-21 relay to operate heat exchanger circulator and provide call for heat exchanger heating to U-Control input.

CONTROL	SETTINGS
CEE NAVIOATION E	

VALUE MUST BE SET (OR VERIFIED) AS INDICATED
 DEFAULT ACCEPTABLE; CHANGE ONLY IF DESIRED

BOILER SETTINGS

BOILER MODEL	Verify model number is correct	
HIGH ALTITUDE	Set to YES if high altitude	
HIGH LIMIT	D	
WWSD TEMP	DEFAULT (70 °F) OR AS REQUIRED	
ADJUST OUTDOOR	DEFAULT (0 °F) OR AS REQUIRED	
ADD'L HEAT DEMAND TYPE	D	
ADD'L HEAT DEMAND TIME	D	
SYSTEM SETTINGS		

	SYSTEM TYPE	Select from list	DHW DIRECT
		Max Supply	190 F
		Max OD Basat	D
	TEMPERATURES	Min OD Reset	D
		Modulate On Diff	D
		Modulate Off Diff	D
BOILER PRIORITY 1		Max On Time	D
	TIMES	Deset Interval	D
DHW	TIMES	Boost Interval	
		Postpump Time:	D
		Circulator 1	ON
	CIRCULATORS	Circulator 2	OFF
		Circulator 3	OFF
			D
		Calcat from list	
	STSTEMITTE	Select from list	Note T (at left)
		Max Supply Min Supply	As required
BOILER PRIORITY 2	TEMPERATURES	Max OD Reset	D (70F) or as req'd
Dedieut zeuee	TEMPERATURES	Min OD Reset	D (0F) or as req'd
Radiant Zones		Modulate On Diff	
		Modulate On Din Max On Time	D
Note 1 —		Min On Time	D
Select system type:	TIMES	Boost Interval	D
RSG = Slab on grade		Prepump Time:	D
RTS = Thin slab		Postpump Time:	
RSU = Below floor	CIRCULATORS	Circulator 1	OFF
RAF = Above floor		Circulator 3	<u>ON</u>
	MAXIMUM RATE		D
	MINIMUM RATE		D
	SYSTEM TYPE	Select from list	DHW SYSTEM
		Max Supply	190 F
		Min Supply Max OD Reset	D
	TEMPERATURES	Min OD Reset	D
		Modulate On Diff	D
RAII FR PRIARITY 3		Modulate Off Diff	D
		Min On Time	P
Heat exchanger	TIMES	Boost Interval	D
<30% of total heat loss)		Prepump Time:	D
		Postpump Time:	D
		Circulator 1	OFF
	CIRCULATORS	Circulator 2 Circulator 3	OFF
	MAXIMUM RATE		D
			D
	Circulator 1		D
CIRCULATOR EXERCISING	Circulator 2		D
	Circulator 3		D
	Circulator 1		D
	Circulator 3		D



LEGEND

J.

***** = Supplied by installer

- DHW circulator *
- BOILER circulator (shipped loose with boiler)
- Radiant circulator *
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- Radiant zone end switches *
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- **10** Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- **12** Heat exchanger
- 14 Heat exchanger aquastat or controller
- 15 WMR-21, 2-pole relay for heat exchanger circulator operation *
- 16 Heat exchanger circulator *
- 21 Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves *
- 24 Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- **26** Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)
- **34** Zone valves
- 35 By-pass pressure regulator





Multi-zone RADIANT | DHW (Direct-connected) | Small BASEBOARD zone (<30% of total heat loss)

Purpose

- Radiant heating circuit with single or multiple zones (zone valves). Multiple-zone wiring not shown must be provided using a zone controller or connecting zone valve end switches.
- Single-zone baseboard heating for a small space (heating load less than 30% of total heat loss alternatively, see Application 7a, which does not limit load sizes).
- DHW piped directly to the boiler.
- DHW priority space heating and heater exchanger heating are disabled during call for heat from water heater.

U-Control setting notes

- See the table at right for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.
- Select DHW DIRECT for the DHW BOILER PRIORITY 1. This informs the control that the DHW tank is directly connected to the boiler.

Circulators and piping

Piping must be primary/secondary as shown.

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping — see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently — see boiler manual and other applications in this guide.
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

RADIANT

- Size circulators for required flow.
- Radiant circulators supplied by installer.



See **Application 7a**, page 22, for radiant heating using independent temperature control for the radiant zone.

BASEBOARD

- Baseboard load must be less than 30% of total heat loss.
- Size circulator for required flow.
- Baseboard circulator supplied by installer.

BOILER

- See boiler manual for sizing.
- Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

- Connect field wiring as shown on next page.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each if load is higher, provide a circulator relay or contactor for circulator power.
- Provide WMR-21 relay to operate baseboard circulator and provide call for baseboard heating to U-Control input.
- If using multiple zones, provide components and wiring needed to operate zone components and provide call for heat to the U-control input.

-CONTROL	SETTINGS
(SEE NAVIGATION F	LOW BELOW)

VALUE MUST BE SET (OR VERIFIED) AS INDICATED
 DEFAULT ACCEPTABLE; CHANGE ONLY IF DESIRED

BOILER SETTINGS

D

BOILER MODEL	Verify model number is correct
HIGH ALTITUDE	Set to YES if high altitude
HIGH LIMIT	D
WWSD TEMP	DEFAULT (70 °F) OR AS REQUIRED
ADJUST OUTDOOR	DEFAULT (0 °F) OR AS REQUIRED
ADD'L HEAT DEMAND TYPE	D
ADD'L HEAT DEMAND TIME	D

SYSTEM SETTINGS

	SYSTEM TYPE	Select from list	DHW DIRECT
		Max Supply	190 F
	TEMPERATURES	Max OD Reset	D
		Min OD Reset	D
		Modulate Off Diff	D
BOILER PRIORITY 1		Max On Time	D
DHW	TIMES	Boost Interval	D
		Prepump Time: Postpump Time:	D
		Circulator 1	ON
	CIRCULATORS	Circulator 2 Circulator 3	OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
	SYSTEM TYPE	Select from list	Note 1 (at left)
		Max Supply	As required
BOILER PRIORITY 2	TEMPERATURES	Max OD Reset	D (70F) or as req'd
	TEMPERATURES	Min OD Reset	D (0F) or as req'd
Radiant		Modulate On Diff	D D
		Max On Time	D
Note 1 —		Min On Time	D
Select system type:	TIMES	Boost Interval	D
RTS = Thin slah		Prepump Time: Postpump Time:	D
RSU = Below floor		Circulator 1	OFF
RAF = Above floor	CIRCULATORS	Circulator 2	
	MAXIMUM RATE	onculator 5	D
	MINIMUM RATE		D
	SYSTEM TYPE	Select from list	FTB or CIB
		Max Supply Min Supply	180 F
	TEMPERATURES	Max OD Reset	D (70F) or as req'd
		Min OD Reset	D (0F) or as req'd
BOILER PRIORITY 3		Modulate Off Diff	D
Decelerat		Min On Time	P
Baseboard	TIMES	Boost Interval	D
(Finned tube or cast iron)		Prepump Time:	D
(<30% of total heat loss)		Postpump Time:	D
	CIRCUI ATORS	Circulator 1 Circulator 2	OFF
		Circulator 3	OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
CIDCIII ATAD EVEDRICING	Circulator 1		D
	Circulator 3		D
	Circulator 1		D
FREEZE PRUIEGI GIRGS	Circulator 2 Circulator 3		D



LEGEND

M

***** = Supplied by installer

- DHW circulator *
- BOILER circulator (shipped loose with boiler)
- Radiant circulator *
- 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- 6 Radiant zone end switches*
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- **10** Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- 14 Baseboard thermostat *
- 15 Weil-McLain WMR-21 two-pole relay to operate baseboard circulator *
- 16 Baseboard circulator *
- 21 Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves *
- 24 Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- 26 Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)
- 34 Zone valves *
- 35 Bypass pressure regulator *





...

Multiple HI-TEMP HEATING zones | DHW (Direct-connected) | Small RADIANT zone (<30 of total heat loss)

Purpose

- Radiant heating and hi-temp (180°F typical) space heating with single or multiple zones (circulator zoning). Hi-temp space heating terminal units can be baseboard, fan coil, radiators or heat exchangers. Fan coils must be equipped with minimum temp aquastats, because their circulators can operate during radiant circuit operation (supply water temperature could be too low for fan coils).
- DHW piped directly to the boiler.
- DHW priority space heating and heater exchanger heating are disabled during call for heat from water heater.

U-Control setting notes

- See the table at right for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.
- Select DHW DIRECT for the DHW BOILER PRIORITY 1. This informs the control that the DHW tank is directly connected to the boiler.

Circulators and piping

Piping must be primary/secondary as shown.

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping - see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently - see boiler manual and other applications in this guide.
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

HI-TEMP SPACE HEATING

- Multiple zones with circulators controlled by Weil-McLain WMCR zone controller.
- Size circulators for required flow.
- Space heating zone circulators supplied by installer.

RADIANT

Radiant load must be less than 30% of total heat loss.

See Application 7a, page 22, for radiant heating using independent temperature control for the radiant zone, with no limit to the radiant load.

- Size circulator for required flow.
- Radiant circulator supplied by installer.

BOILER

- See boiler manual for sizing.
- Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

NOTICE

- Connect field wiring as shown on next page.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each - if load is higher, provide a circulator relay or contactor for circulator power.
- Provide Weil-McLain WMCR circulator zone controller to control all hi-temp zone circulators, sized for the number of zones required.

CONTROL	SETTINGS
(SEE NAVIGATION F	LOW BELOW)

- VALUE MUST BE SET (OR VERIFIED) AS INDICATED - DEFAULT ACCEPTABLE: CHANGE ONLY IF DESIRED

BOILER SETTINGS

D

BOILER MODEL	Verify model number is correct
HIGH ALTITUDE	Set to YES if high altitude
HIGH LIMIT	D
WWSD TEMP	DEFAULT (70 °F) OR AS REQUIRED
ADJUST OUTDOOR	DEFAULT (0 °F) OR AS REQUIRED
ADD'L HEAT DEMAND TYPE	D
ADD'L HEAT DEMAND TIME	D

SYSTEM SETTINGS

	SYSTEM TYPE	Select from list	DHW Direct
		Max Supply	190 F
	TEMPERATURES	Max OD Reset	D
		Min OD Reset	D
		Modulate Off Diff	D
BOILER PRIORITY 1		Max On Time	D
	TIMES	Boost Interval	D
		Prepump Time:	D
		Circulator 1	
	CIRCULATORS	Circulator 2	OFF
		Circulator 3	OFF
	MAXIMUM RATE		D
			D
	SYSTEM TYPE	Select from list	Note 1 (at left)
BOILER PRIORITY 2		Max Supply Min Supply	As required
	TEMPERATURES	Max OD Reset	D (70F) or as req'd
HI-temp space htg.		Min OD Reset	D (0F) or as req'd
		Modulate Off Diff	D
Note 1 —			D
Select system type:		Min On Time	D
FOL = Fan Coll ETP = Finned tube bb	TIMES	Boost Interval	D
FIB = Finned-tube bb CIB = Cast iron bb		Postpump Time:	D
CIR = Cast iron rad		Circulator 1	OFF
Use DHW SYSTEM for	CIRCULATORS	Circulator 2 Circulator 3	ÓN OFF
heat exchangers	MAXIMUM RATE		D
	MINIMUM RATE		D
	SYSTEM TYPE	Select from list	Note 2 (at left)
		Max Supply	As required
BUILER PRIURITY 3		Min Supply Max OD Reset	D (70E) or as regid
Dedient	TEMPERATURES	Min OD Reset	D (0F) or as req'd
Radiant		Modulate On Diff	D
(<30 of total heat loss)		Modulate Off Diff	D
Noto 2		Min On Time	D
Soloct system type:	TIMES	Boost Interval	D
RSG – Slab on grade		Prepump Time:	D
RTS = Thin slab		Circulator 1	OFE
RSU = Below floor	CIRCULATORS	Circulator 2	ON
RAF = Above floor		Circulator 3	ON
	MAXIMUM RATE		D
			D
CIRCIII ATOR FYFRCISING	Circulator 1 Circulator 2		
	Circulator 3		Ď
	Circulator 1		D
FREEZE PROTECT CIRCS	Circulator 2 Circulator 3		D
			5



LEGEND

M

***** = Supplied by installer

- 1 DHW circulator *
- **2** BOILER circulator (shipped loose with boiler)
- 3 Radiant zone circulator *
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- 6 Hi-temp zone thermostat *
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- 10 Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- 14 Radiant zone thermostat *
- 15 Weil-McLain WMCR circulator zone controller (select for number of zones required) *
- 16 Hi-temp zone circulator *
- 21 Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves *
- 24 Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- **26** Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)





Application 7a

Multi-zone HI-TEMP HEATING plus RADIANT (with mixing valve) | DHW (Direct-connected) (No limits on the relative heating loads of radiant or hi-temp space heating circuits)

Purpose

- Radiant heating and hi-temp (180°F typical) space heating with single or multiple zones (circulator zoning). Hi-temp space heating terminal units can be baseboard, fan coil, radiators or heat exchangers.
- Supply water temperature is selected for the hi-temp zones. The mixing valve regulates supply temperature to the lower-temperature radiant zones.
- All circulators (hi temp and radiant) are operated by the Weil-McLain WMCR circulator zone controller.
- DHW piped directly to the boiler.
- DHW priority space heating is disabled during call for heat from water heater.

U-Control setting notes

- See the table at right for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.
- Select DHW DIRECT for the DHW BOILER PRIORITY 1. This informs the control that the DHW tank is directly connected to the boiler.

Circulators and piping

• Piping must be primary/secondary as shown.

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently see boiler manual and other applications in this guide.
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

HI-TEMP SPACE HEATING

- Multiple zones with circulators controlled by Weil-McLain WMCR zone controller.
- Size circulators for required flow.
- All space heating circulators (hi-temp and radiant) supplied by installer.

BOILER

- See boiler manual for sizing.
- Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

- Connect field wiring as shown on next page.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each if load is higher, provide a circulator relay or contactor for circulator power.
- Provide Weil-McLain WMCR circulator zone controller to control all space heating zone circulators (hi-temp and radiant), sized for the number of zones required.

U-	CONTROL	SETTINGS
	,	

(SEE NAVIGATION FLOW BELOW)

VALUE MUST BE SET (OR VERIFIED) AS INDICATED
 DEFAULT ACCEPTABLE; CHANGE ONLY IF DESIRED

BOILER SETTINGS

BOILER MODEL	Verify model number is correct
HIGH ALTITUDE	Set to YES if high altitude
HIGH LIMIT	D
WWSD TEMP	DEFAULT (70 °F) OR AS REQUIRED
ADJUST OUTDOOR	DEFAULT (0 °F) OR AS REQUIRED
ADD'L HEAT DEMAND TYPE	D
ADD'L HEAT DEMAND TIME	D

	SYSTEM SE	TTINGS	
	SYSTEM TYPE	Select from list	DHW Direct
		Max Supply	190 F
	TEMPERATURES	Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D
BOILER PRIORITY 1		Max On Time	D
DHW	TIMES	Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	ON OFF OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
	SYSTEM TYPE	Select from list	Select
BOILER PRIORITY 2 Space heating — select type most typical of hi-temp terminal units and	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	As required D D (70F) or as req'd D (0F) or as req'd D D
	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
temp required	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
	TEMPERATURES	Select from list Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	
BUILER PRIJKITY 3 Not used	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
/	MAXIMUM RATE		D
/ \	MINIMUM RATE		D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		D D D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3		D D D



LEGEND

J.

\star = Supplied by installer

- 1 DHW circulator *
- 2 BOILER circulator (shipped loose with boiler)
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- 6 Hi-temp zone thermostats *
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- 10 Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- 15 Weil-McLain WMCR circulator zone controller *
- 16 Radiant zone circulators *
- 17 Hi-temp zone circulators *
- 18 Radiant zone thermostat *
- 21 Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves *
- 24 Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- 26 Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- 29 Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)
- 40 Mixing valve controls supply temperature to radiant zones *
- 41 Check valve *





Multi-zone BASEBOARD (Zone valves + WMZV controller) | DHW (Direct-connected)

CIRCULATOR EXERCISING

FREEZE PROTECT CIRCS

Circulator 2

Circulator 3 Circulator 1

Circulator 2

Circulator 3

Purpose

- Space heating with multiple baseboard zones.
- Zoning with zone valves.
- DHW piped directly to the boiler.
- DHW priority space heating and heater exchanger heating are disabled during call for heat from water heater.

U-Control setting notes

- See the table at right for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.
- Select DHW DIRECT for the DHW BOILER PRIORITY 1. This informs the control that the DHW tank is directly connected to the boiler.

Circulators and piping

• Piping must be primary/secondary as shown.

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping — see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently — see boiler manual and other applications in this guide.
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

BASEBOARD

- Size for required flow.
- System circulator supplied by installer.
- Multiple zones (with zone valves and bypass pressure regulator by installer).

BOILER

- See boiler manual for sizing.
- Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

- Connect field wiring as shown on next page.
- This application applies only to multiple-zone space heating, using Weil-McLain zone controller.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each if load is higher, provide a circulator relay or contactor for circulator power.
- Provide Weil-McLain WMZV zone valve controller.

U-CONTROL SETTINGS (SEE NAVIGATION FLOW BELOW) VALUE MUST BE SET (OR VERIFIED) AS INDICATED
 DEFAULT ACCEPTABLE; CHANGE ONLY IF DESIRED

BOILER SETTINGS

D

BOILER MODEL	Verify model number is correct		
HIGH ALTITUDE	Set to YES if high altitude		
HIGH LIMIT	D		
WWSD TEMP	DEFAULT (70 °F) OR AS REQUIRED		
ADJUST OUTDOOR	DEFAULT (0 °F) OR AS REQUIRED		
ADD'L HEAT DEMAND TYPE	D		
ADD'L HEAT DEMAND TIME	D		

	SYSTEM TYPE	Select from list	DHW Direct
		Max Supply	190 F
	TEMPERATURES	Max OD Reset	D
		Min OD Reset	D
		Modulate On Diff	D
BOILER PRIORITY 1		Max On Time	D
	TIMES	Boost Interval	D
DHW		Prepump Time:	D
		Postpump Time:	D
		Circulator 1	ON OFF
	CIRCULATORS	Circulator 2	OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
	SYSTEM TYPE	Select from list	FTB or CIB
		Max Supply	180 F
		Min Supply Max OD Reset	D (70E) or as reg
	TEMPERATURES	Min OD Reset	D (0F) or as req'o
		Modulate On Diff	D
BOILER PRIORITY 2		Modulate Off Diff	D
	TIMES	Max On Time	D
Baseboard (Finned tube or cast iron)		Boost Interval	D
		Prepump Time:	D
		Postpump Time:	D
		Circulator 1	OFF
	OINCOLATONO	Circulator 3	ON
	MAXIMUM RATE		D
	MINIMUM RATE		D
\backslash /	SYSTEM TYPE	Select from list	D
\backslash /		Max Supply	D
		Min Supply Max OD Reset	D
	TEMPERATURES	Min OD Reset	D
		Modulate On Diff	D
		Modulate Off Diff	D
		Min On Time	D
	TIMES	Boost Interval	D
NOT USED		Prepump Time:	D
		Postpump Time:	D
	CIRCUILATORS	Circulator 1 Circulator 2	D
	OINGOLATONO	Circulator 3	D
	MAXIMUM RATE		D
/	MINIMUM RATE		D
	Circulator 1		D

D

D



LEGEND

M

***** = Supplied by installer

- 1 DHW circulator *
- **2** BOILER circulator (shipped loose with boiler)
- 3 SYSTEM circulator *
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- 6 Baseboard zone thermostats *
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- 10 Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- 21 Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves *
- 24 Air separator with automatic air vent *
- **25** Diaphragm-type expansion tank *
- 26 Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)
- 34 Zone valves *
- 35 Bypass pressure regulator *
- 36 Weil-McLain WMZV zone valve controller *







Multi-zone BASEBOARD (Circulators + WMCR controller) | DHW (Direct-connected)

Purpose

- Space heating with multiple baseboard zones.
- Zoning with circulators.
- DHW piped directly to the boiler.
- DHW priority space heating and heater exchanger heating are disabled during call for heat from water heater.

U-Control setting notes

- See the table at right for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.
- Select DHW DIRECT for the DHW BOILER PRIORITY 1. This informs the control that the DHW tank is directly connected to the boiler.

Circulators and piping

• Piping must be primary/secondary as shown.

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently — see boiler manual and other applications in this guide.
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

BASEBOARD

- Size for required flow.
- Baseboard zone circulators supplied by installer.
- Multiple zones.

BOILER

- See boiler manual for sizing.
- Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

- Connect field wiring as shown on next page.This application applies only to multiple-zone space heating,
- Inis application applies only to multiple-zone space neating, using Weil-McLain zone controller.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each if load is higher, provide a circulator relay or contactor for circulator power.
- Provide Weil-McLain WMCR circulator zone controller.

U-CONTROL SETTINGS (SEE NAVIGATION FLOW BELOW) VALUE MUST BE SET (OR VERIFIED) AS INDICATED
 DEFAULT ACCEPTABLE; CHANGE ONLY IF DESIRED

BOILER SETTINGS

BOILER MODEL	Verify model number is correct		
HIGH ALTITUDE	Set to YES if high altitude		
HIGH LIMIT	D		
WWSD TEMP	DEFAULT (70 °F) OR AS REQUIRED		
ADJUST OUTDOOR	DEFAULT (0 °F) OR AS REQUIRED		
ADD'L HEAT DEMAND TYPE	D		
ADD'L HEAT DEMAND TIME	D		
SVETEM SETTINGS			

	SYSTEM TYPE	Select from list	DHW Direct
		Max Supply	190 F
	TEMPERATURES	Max OD Reset	D
		Min OD Reset	D
		Modulate Off Diff	D
BOILER PRIORITY 1		Max On Time	D
		Max on Thine	U
	TIMES	Boost Interval	D
		Prepump Time:	D
		Postpump Time:	D
		Circulator 1	ON
	CIRCULATORS	Circulator 2 Circulator 3	OFF
			D
			D
		Salact from list	ETP or CIP
	STSTEWITTE	Mey Supply	
		Min Supply	180 F
	TEMPERATURES	Max OD Reset	D (70F) or as reg'd
	TEMPERATURES	Min OD Reset	D (0F) or as req'd
		Modulate On Diff	D
BOILER PRIORITY 2		Modulate Off Diff	D
		Max On Time	D
Baseboard	TIMES	Min On Time Reast Interval	D
(Einpad tube or east iron)	TIMES	Prepump Time:	D
(Finited tube of cast fion)		Postpump Time:	D
		Circulator 1	OFF
	CIRCULATORS	Circulator 2	ON
		Circulator 3	OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
\backslash /	SYSTEM TYPE	Select from list	D
		Max Supply	D
		Max OD Reset	
	TEMPERATURES	Min OD Reset	D
		Modulate On Diff	D
		Modulate Off Diff	D
BUILEK PRIUKI I Y 3			_
X	TIMES	Min On Time	D
Not used 🔪	TIMES	Prenumn Time	ם ו
		Postpump Time:	D
		Circulator 1	D
	CIRCULATORS	Circulator 2	D
		Circulator 3	D
	MAXIMUM RATE		D
/ \	MINIMUM RATE		D
	Circulator 1		D
CIRCULATOR EXERCISING	Circulator 2		D
	Circulator 3		D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2		D
	Oliveral at an O		5



LEGEND

J.M

***** = Supplied by installer

- 1 DHW circulator *
- 2 BOILER circulator (shipped loose with boiler)
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- 6 Baseboard zone thermostats *
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- 10 Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- 12 Weil-McLain WMCR circulator zone controller *
- 16 Baseboare zone circulators *
- 21 Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves *
- 24 Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- **26** Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)







Multi-zone FAN COILS (Circs. + WMCR contr.) | DHW (Direct-connected) | Small RADIANT zone (<30% of total heat loss)

Purpose

- Space heating with multiple fan coil zones, circulator zoning. Single radiant zone for small space (heating load less than 30% of to-
- tal heat loss alternatively, see Application 7a, which does not limit load sizes). Fan coil zones are disabled during radiant call for heat.
- DHW piped directly to the boiler.
- DHW priority space heating and heater exchanger heating are disabled during call for heat from water heater.

U-Control setting notes

- See the table at right for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.
- Select DHW DIRECT for the DHW BOILER PRIORITY 1. This informs the control that the DHW tank is directly connected to the boiler.

Circulators and piping

Piping must be primary/secondary as shown.

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping - see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently - see boiler manual and other applications in this guide.
- U-Control is set for DHW priority -- space heating will be discontinued during a call for DHW.

FAN COIL

- Multiple zones with circulators controlled by Weil-McLain WMCR zone controller.
- Size circulators for required flow. Fan coil circulators supplied by installer.

RADIANT

- Radiant load must be less than 30% of total heat loss.
- Size circulator for required flow. Radiant circulator supplied by installer.

See Application 7a, page 22, for radiant heating using independent temperature control for the radiant zone, with no limit to the radiant load.

BOILER

- See boiler manual for sizing.
- Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

NOTICE

- Connect field wiring as shown on next page.
- This application applies only to multiple-zone space heating, using Weil-McLain zone controller.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each - if load is higher, provide a circulator relay or contactor for circulator power.
- Provide Weil-McLain WMCR circulator zone controller to control fan coil zone circulators.
- Provide a single-pole normally-closed contact relay, 120 VAC coil, to disable fan coil zones during radiant call for heat.



The single-pole relay can be omitted if the fan coil units are equipped with minimum temperature aquastats.

J -	GO	N T	RO	L :	SE	ТΤ	'IN	G
	10==				~			

iS (SEE NAVIGATION FLOW BELOW)

- VALUE MUST BE SET (OR VERIFIED) AS INDICATED - DEFAULT ACCEPTABLE: CHANGE ONLY IF DESIRED

BOILER SETTINGS

BOILER MODEL	Verify model number is correct
HIGH ALTITUDE	Set to YES if high altitude
HIGH LIMIT	D
WWSD TEMP	DEFAULT (70 °F) OR AS REQUIRED
ADJUST OUTDOOR	DEFAULT (0 °F) OR AS REQUIRED
ADD'L HEAT DEMAND TYPE	D
ADD'L HEAT DEMAND TIME	D

	STSTEM SE	TTINGS	
	SYSTEM TYPE	Select from list	DHW Direct
	TEMPERATURES	Max Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	190 F D D D D
<i>Boiler Priority 1</i> Dhw	TIMES	Max On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	ON OFF OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
	SYSTEM TYPE	Select from list	FCL
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	190 F D D (70F) or as req'd D (0F) or as req'd D D
<i>BOILER PRIORITY 2</i> Fan coil zones	TIMES	Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
	SYSTEM TYPE	Select from list	Note 1 (at left)
BOILER PRIORITY 3 Radiant zone <30% of total heat loss	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	As required D D (70F) or as req'd D (0F) or as req'd D D
Note 1 — Select system type: RSG = Slab on grade	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D D
RTS = Thin slab RSU = Below floor RAF = Above floor	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON ON
	MAXIMUM RATE		D
	MINIMUM RATE		D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		D D D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3		D D D



LEGEND

I

***** = Supplied by installer

- 1 DHW circulator *
- 2 BOILER circulator (shipped loose with boiler)
- 3 Radiant zone circulator *
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- 6 Fan coil zone thermostats *
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- **10** Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- 12 Weil-McLain WMCR circulator zone controller *
- **13** SPST relay with 120 VAC coil *
- 14 Radiant zone thermostat *
- 16 Fan coil zone circulators *
- 21 Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves *
- 24 Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- 26 Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)





CAST IRON RADIATORS | DHW (Direct-connected) | Small RADIANT zone (<30% of total heat loss)

Purpose

- Single cast iron radiator zone.
- Single radiant zone for small space (heating load less than 30% of total heat loss alternatively, see Application 7a, which does not limit load sizes). Radiator zone is disabled during radiant call for heat.
- DHW piped directly to the boiler.
- DHW priority space heating is disabled during call for heat from water heater.

U-Control setting notes

- See the table at right for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.
- Select DHW DIRECT for the DHW BOILER PRIORITY 1. This informs the control that the DHW tank is directly connected to the boiler.

Circulators and piping

• Piping must be primary/secondary as shown.

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping — see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently see boiler manual and other applications in this guide.
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

RADIATORS

- Size circulator for required flow.
- Radiator zone circulator supplied by installer.

RADIANT

• Radiant load must be less than 30% of total heat loss.



See **Application 7a**, page 22, for radiant heating using independent temperature control for the

radiant zone, with no limit to the radiant load.Size circulator for required flow. Radiant circulator supplied by installer.

BOILER

- See boiler manual for sizing.
- Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

- Connect field wiring as shown on next page.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each if load is higher, provide a circulator relay or contactor for circulator power.
- Provide WMR-21 relay to operate radiator circulator(s) and provide call for radiator zone heating to U-Control input.
- If using multiple zones, provide components and wiring needed to operate zone components and provide call for heat to the U-control input.

-CONTROL	SETTINGS
CEE NAVICATION E	

VALUE MUST BE SET (OR VERIFIED) AS INDICATED
 DEFAULT ACCEPTABLE; CHANGE ONLY IF DESIRED

BOILER SETTINGS

BOILER MODEL	Verify model number is correct
HIGH ALTITUDE	Set to YES if high altitude
HIGH LIMIT	D
WWSD TEMP	DEFAULT (70 °F) OR AS REQUIRED
ADJUST OUTDOOR	DEFAULT (0 °F) OR AS REQUIRED
ADD'L HEAT DEMAND TYPE	D
ADD'L HEAT DEMAND TIME	D

	JIJIEM JE	TINGS	
	SYSTEM TYPE	Select from list	DHW Direct
	TEMPERATURES	Max Supply Max OD Reset	190 F
		Min OD Reset Modulate On Diff Modulate Off Diff	D D D
BOILER PRIORITY 1		Max On Time	D
DHW	TIMES	Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	ON OFF OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
	SYSTEM TYPE	Select from list	CIR
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	180 F D D (70F) or as req'd D (0F) or as req'd D D
BOILER PRIORITY 2		Max On Time	D
	TIMES	Min On Time Boost Interval	D
Radiator zone		Prepump Time: Postpump Time:	D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
	SYSTEM TYPE	Select from list	Note 1 (at left)
BOILER PRIORITY 3	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset	As required D D (70F) or as req'd D (0F) or as req'd
<30% of total heat loss		Modulate On Diff Modulate Off Diff	D D
Note 1 — Select system type: RSG = Slab on grade	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
RTS = Thin slab RSU = Below floor	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON ON
AF = Above floor	MAXIMUM RATE		D
	MINIMUM RATE		D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		D D D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3		D D D



LEGEND

J.

***** = Supplied by installer

- 1 DHW circulator *
- 2 BOILER circulator (shipped loose with boiler)
- 3 Radiant circuit circulator *
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- 6 Radiator zone thermostat *
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- **10** Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- 14 Radiant thermostat *
- 15 Weil-McLain WMR-21 relay *
- 16 Radiator zone circulator *
- 21 Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves *
- **24** Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- 26 Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)





- VALUE MUST BE SET (OR VERIFIED) AS INDICATED

Application 12

FAN COIL zone | BASEBOARD zone | Small RADIANT zone (<30% of total heat loss)

U-CONTROL SETTINGS

Purpose

- Space heating with a single zone of baseboard, single zone of radiant and single zone of fan coil.
- The radiant load must be no more than 30% of the total heating load to use the control strategy of this application. Alternatively, see Application 7a, which does not limit load sizes.
- Zoning with circulators.

U-Control setting notes

See the table at right for required and optional settings. To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.

Circulators and piping

Piping must be primary/secondary as shown.

FAN COIL

- Size circulator for required flow.
- Fan coil circulator supplied by installer.

BASEBOARD

- Size circulator for required flow.
- Baseboard circulator supplied by installer.

RADIANT

Radiant load must be less than 30% of total heat loss.

NOTICE

See Application 7a, page 22, for radiant heating using independent temperature control for the radiant zone, with no limit to the radiant load.

Size circulator for required flow. Radiant circulator supplied by installer.

BOILER

- See boiler manual for sizing.
- Circulator shipped loose with boiler. Boiler loop piping can be provided using optional Easy-Up
- Manifolds, available from Weil-McLain (see page 5).

Wiring

- Connect field wiring as shown on next page.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each — if load is higher, provide a circulator relay or contactor for circulator power.
- Provide WMR-21 relay to operate baseboard circulator and provide call for heat to U-Control.

(SEE NAVIGATION FLOW BE	elow)	D	- DEFAULT ACCEPTABLE;	CHANGE ONLY IF DESIRED
BOILER SETTINGS				
			Varifium a dal m	un han ie aanvoot
HIGH ALITIODE			Set to YES If	nign altitude
HIGH LIMIT				D
WWSD TEMP			DEFAULT (70 °F)	OR AS REQUIRED
ADJUST OUTDOOR			DEFAULT (0 °F)	OR AS REQUIRED
ADD'L HEAT DEMAND TYPE			Тү	ре 1
ADD'L HEAT DEMAND TIME			DEFAULT (0 MINUTES)
	SYSTE	M SE	TTINGS	
	SYSTEM TY	PE	Select from list	FCL
	TEMPERAT	URES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate Of Diff Modulate Off Diff	190 F D Default Default D D
BOILER PRIORITY 1			Max On Time	D (30 minutes)
Fan coil zone	TIMES		Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATO	ORS	Circulator 1 Circulator 2 Circulator 3	ON ON OFF
	MAXIMUM			D
	MINIMUM R	ATE		D
	SYSTEMTY	PE	Select from list	FTB or CIB
RNII FR PRINRITY 2	TEMPERAT	URES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	180 F D Default Default D D
Baseboard (Finned tube or cast iron)	TIMES		Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D (30 minutes) D D D D D
	CIRCULATO	ORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF
	MAXIMUM			D
			Salaat from list	
BOILER PRIORITY 3 Radiant zone <30% of total heat loss	TEMPERAT	URES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	As required Default Default D
Note 1 — Select system type: RSG = Slab on grade	TIMES		Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D D
RTS = Thin slab RSU = Below floor RAF = Above floor	CIRCULATO	ORS	Circulator 1 Circulator 2 Circulator 3	OFF ON ON
	MAXIMUM			D
		AIE		D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3			D D D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3			D D D





J.M



Single-zone BASEBOARD | DHW (System, as zone)

Purpose

- Space heating with single zone of baseboard (finned tube or cast iron). This application can be adapted for multiple baseboard zones if piping components and controls are added to control the zone circulators or zone valves and provide a call for heat signal to the U-Control.
- DHW piped as a separate zone.
- DHW priority space heating is disabled during call for heat from water heater.

U-Control settings

- See the table at right for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.
- Select DHW SYSTEM for the DHW BOILER PRIORITY 1. This informs the control that the DHW tank is a system zone, not directly connected to the boiler.

Circulators and piping

• Piping must be primary/secondary as shown.

DHW

- DHW circulator must be sized for required flow and head loss.
- DHW circulator supplied by installer.
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

BASEBOARD

- Single zone. Multiple zones can be used if zone controller and piping components are added.
- Size circulator for required flow.
- Baseboard circulator supplied by installer.

BOILER

- See boiler manual for sizing.
- · Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

- Connect field wiring as shown on next page.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each if load is higher, provide a circulator relay or contactor for circulator power.
- If using multiple zones of baseboard, provide components and wiring needed to operate zone components and provide call for heat to the U-control input.

U-CONTROL	SETTINGS
(SEE NAVIGATION E	I OW BELOW)

WALUE MUST BE SET (OR VERIFIED) AS INDICATED
 DEFAULT ACCEPTABLE; CHANGE ONLY IF DESIRED

BOILER SETTINGS

BOILER MODEL	Verify model number is correct
HIGH ALTITUDE	Set to YES if high altitude
HIGH LIMIT	D
WWSD TEMP	DEFAULT (70 °F) OR AS REQUIRED
ADJUST OUTDOOR	DEFAULT (0 °F) OR AS REQUIRED
ADD'L HEAT DEMAND TYPE	D
ADD'L HEAT DEMAND TIME	D

BOILER PRIORITY 1 SYSTEM TYPE Select from list DHW/SYSTEM BOILER PRIORITY 1 TEMPERATURES Max OD Reset Modulate Off Diff D DHW TIMES Boost Interval Prepump Time: Desptump Time: D D D BOILER PRIORITY 1 TIMES Boost Interval Prepump Time: D D BOILER PRIORITY 2 TIMES Boost Interval Prepump Time: D D BOILER PRIORITY 2 TIMES Select from list FTB or CIB BOILER PRIORITY 2 TEMPERATURES Max Supply Min Supply Min Supply Max OD Reset Min OD Reset Min OD Reset Min OD Time D BOILER PRIORITY 2 TIMES Select from list FTB or CIB BOILER PRIORITY 2 TIMES Select from list FTB or CIB BOILER PRIORITY 2 TIMES Select from list FTB or CIB BOILER PRIORITY 2 TIMES Select from list D BOILER PRIORITY 3 TIMES Max OD Time D D Not used TIMES Select from list D BOILER PRIORITY 3 TIMES Select from list D Not used CIRCULATORS Circulator 3 D CIRCULATORS TIMES Select from list D BOILER PRIORITY 3 TIMES Select from list D <		3131EM 3E	TINGS	
BOILER PRIORITY 1 TEMPERATURES Max OD Reset Min OD Reset Modulate Of Diff D DHW TIMES Boost Interval Prepump Time: Destpump Time: Postpump Time: Destpump Time: Destpump Time: D D BOILER PRIORITY 2 MaxIMUM RATE D BOILER PRIORITY 2 TIMES Select from list BOILER PRIORITY 2 TEMPERATURES Max Supply Max Supply 180 F BOILER PRIORITY 2 TEMPERATURES Max Supply Max Supply 180 F BOILER PRIORITY 2 TEMPERATURES Max Supply Max Supply D BOILER PRIORITY 2 TEMPERATURES Max Supply Max Supply D BOILER PRIORITY 2 TEMPERATURES Max Supply Max OD Reset Min OD Reset Min On Time D D BOILER PRIORITY 2 TIMES Select from list D BOILER PRIORITY 2 TIMES Max On Time D D BOILER PRIORITY 3 TIMES Select from list D Not used TEMPERATURES Circulator 1 OFF BOILER PRIORITY 3 TIMES Select from list D BOILER PRIORITY 3 TIMES Select from list D Circulator 1 Circulator 2 ON ON BOILER PRIORITY 3 TIMES Select from list D Circulator 1 <td< th=""><th></th><th>SYSTEM TYPE</th><th>Select from list</th><th>DHW SYSTEM</th></td<>		SYSTEM TYPE	Select from list	DHW SYSTEM
BOILER PRIORITY 1 TEMPERATURES Max OD Reset Min OD Reset Modulate On Diff Modulate Of Diff D DHW TIMES Boost Interval Prepung Time: D D CIRCULATORS Circulator 1 ON CIRCULATORS Circulator 2 ON MAX MUM RATE D D SYSTEM TYPE Select from list FTB or CIB MAXIMUM RATE D D BOILER PRIORITY 2 SYSTEM TYPE Select from list Baseboard (Finned tube or cast iron) TIMES Max On Time Min OD Reset Modulate Of Diff D MINIMUM RATE D D OFF CIRCULATORS Circulator 3 OFF Min OD Time Min OD Time D D Postpump Time: D D D Baseboard (Finned tube or cast iron) TIMES Select from list D MINIMUM RATE D D MINIMUM RATE D D SYSTEM TYPE Select from list D SYSTEM TYPE Select from list D MINIMUM RATE D D <			Max Supply	190 F
BOILER PRIORITY 1 Min OD Reset Modulate On Diff Modulate OD Diff D DHW TIMES Boost Interval Prepunp Time: D D Image: Descent problem (CIRCULATORS) Circulator 1 D CIRCULATORS Circulator 1 ON Circulator 2 ON OFF MAXIMUM RATE D D BOILER PRIORITY 2 Select from list FTB or CIB Baseboard (Finned tube or cast iron) TIMES Select from list PTB or CIB Max OD Reset Min OD Reset Min OD Reset Min OD Reset Min OD Reset Min OD Reset Min OD Time D D D Baseboard (Finned tube or cast iron) TIMES Max OD Reset Min On Time D D Record Time D D D RAXIMUM RATE D D D Prepung Time: Prepung Time: D D D Boiller PRIORITY 2 CIRCULATORS Circulator 1 OFF Maximum RATE MINIMUM RATE D D D Boiller PRIORITY 3 TIMES Select from list D Not used TIMES Select from list D Maximum RATE MINIMUM RATE D D Boiller PRIORITY 3 TIMES Select from list D Not used TIMES Max Supply Min Op Reset Modulate Of Diff D <th></th> <th></th> <th>Max OD Reset</th> <th>D</th>			Max OD Reset	D
BOILER PRIORITY 1 Modulate Of Diff D DHW TIMES Boost Interval Prepunp Time: D CIRCULATORS Circulator 1 ON CIRCULATORS Circulator 2 ON CIRCULATORS Circulator 3 OFF MAXIMUM RATE D D MINIMUM RATE D D SYSTEM TYPE Select from list FTB or CIB Baseboard TEMPERATURES Max On Time D Baseboard TIMES Max On Time D Finned tube or cast iron) TIMES Circulator 2 ON CIRCULATORS Circulator 3 ON D RAXIMUM RATE D D D Baseboard TIMES Max On Time D Prepunp Time: D D D Prepunp Time: D D D VINCLATORS Circulator 1 OFF Circulator 3 ON Max On Time D Boost Interval D D D Prepunp Time: D D D VINCLATORS Circulator 2 ON ON MAXIMUM RATE D D D BOILER PRIORITY 3 TIMES <th></th> <th>TEMPERATURES</th> <th>Min OD Reset</th> <th>D</th>		TEMPERATURES	Min OD Reset	D
BoilLER PRIORITY 1 Modulate Off Diff D DHW TIMES Boost Interval Prepunp Time: Destpump Time: Destpump Time: D D CIRCULATORS Circulator 1 Circulator 2 Circulator 3 ON ON OFF MAXIMUM RATE D BOILER PRIORITY 2 Select from list MAXIMUM RATE TIMES BOILER PRIORITY 2 TEMPERATURES Max Supply Max OD Reset Modulate Of Diff D BOILER PRIORITY 2 TIMES Select from list Max On Time Modulate Of Diff D BOILER PRIORITY 2 TIMES Select from list Max On Time Min OD Reset Modulate Of Diff D CIRCULATORS Circulator 1 OFF D MAXIMUM RATE D D D BOILER PRIORITY 3 TIMES Select from list Max On Time D D MAXIMUM RATE D D D BOILER PRIORITY 3 TIMES Select from list D D MAXIMUM RATE D D D BOILER PRIORITY 3 TIMES Select from list D D Not used TIMES Select from list D D CIRCULATORS TIMES Select from list D D CIRCULATORS TIMES Select from list D D BOILER PRIORITY 3 TIMES D			Modulate On Diff	D
DHW TIMES Boost Interval Prepump Time: Postpump Time: D D CIRCULATORS Circulator 1 ON CIRCULATORS Circulator 2 OFF MAXIMUM RATE D MINIMUM RATE D SYSTEM TYPE Select from list FTB or CIB Max Supply Max Supply 180 F Max On Time D Baseboard TIMES Finned tube or cast iron) TIMES CIRCULATORS Circulator 1 Circulator 3 OFF MAXIMUM RATE D Prepump Time: D Prepump Time: D CIRCULATORS Circulator 1 Circulator 3 OFF Min On Time D Bootter Prior 1 OFF MiNIMUM RATE D Prepump Time: D Prepump Time: D Prepump Time: D MiNIMUM RATE D SYSTEM TYPE Select from list MINIMUM RATE D SYSTEM TYPE Select from list SYSTEM TYPE Select from list D Max Supply MINIMUM RATE D MOdulate Of Diff D <t< th=""><th>RNII FR PRINRITY 1</th><td></td><td>Modulate Off Diff</td><td>D</td></t<>	RNII FR PRINRITY 1		Modulate Off Diff	D
DHW TIMES Boost Interval Prepump Time: Postpump Time: Dotum Time: Postpump Time: D D CIRCULATORS Circulator 1 Circulator 2 Circulator 3 ON OFF MAXIMUM RATE D MAXIMUM RATE D SYSTEM TYPE Select from list FTB of CIB SYSTEM TYPE Select from list D TEMPERATURES Max On Time Modulate Of Diff Min OD Reset Min OD Reset Min OD Reset Min OD Time Boost Interval Postpump Time: D TIMES CIRCULATORS CIRCULATOR			Max on Time	D
Prepump Time: D Postpump Time: D CIRCULATORS Circulator 1 CIRCULATORS Circulator 2 MAXIMUM RATE D MAXIMUM RATE D SYSTEM TYPE Select from list FTB or CIB Max Supply Min Supply Max OR Reset D Modulate On Diff D D OFF Max Or Time D Max On Time D Max On Time D Max On Time D Bost Interval D Prepump Time: D Circulator 1 OFF Circulator 3 ON Circulator 4 D Prostpump Time: D D ON Circulator 3 ON Max ON Time D Bost Interval D Prepump Time: D Variant Ante D Maximum RATE D SYSTEM TYPE Select from list D D Maximum RATE D Max OR Reset D Min OD Reset D Modulate Of Diff D TEMPERATURES Max Supply	рнм	TIMES	Boost Interval	D
BOILER PRIORITY 2 CIRCULATORS Circulator 1 Circulator 1 ON Circulator 3 BOILER PRIORITY 2 TEMPERATURES Max Supply Max OD Reset Modulate On Diff 180 F Baseboard (Finned tube or cast iron) TIMES Max On Time Boost Interval Prepump Time: D CIRCULATORS Circulator 1 Circulator 2 OFF D BOILER PRIORITY 3 TIMES Max On Time Boost Interval Prepump Time: D BOILER PRIORITY 3 TIMES Select from list D BOILER PRIORITY 3 TIMES Max On Time Boost Interval Prepump Time: D BOILER PRIORITY 3 TIMES Select from list D BOILER PRIORITY 3 TIMES Select from list D CIRCULATORS Circulator 1 Circulator 2 ON BOILER PRIORITY 3 TIMES Select from list D Not used TIMES Min On Time Boost Interval Prepump Time: D CIRCULATORS Circulator 1 Circulator 2 D CIRCULATOR Circulator 1 Circulator 3 D CIRCULATOR EXERCISING Circulator 1 Circulator 3 D CIRCULATOR EXERCISING Circulator 1 Circulator 3 D			Prepump Time:	D
CIRCULATORS Circulator 1 Circulator 2 Circulator 3 ON MAXIMUM RATE D MINIMUM RATE D SYSTEM TYPE Select from list FTB or CIB SYSTEM TYPE Select from list FTB or CIB BOILER PRIORITY 2 Max Supply Min Supply D Baseboard (Finned tube or cast iron) TIMES Max On Time Boost Interval Prepump Time: D D CIRCULATORS Circulator 1 Circulator 3 OFF MAXIMUM RATE D D MAXIMUM RATE D MAXIMUM RATE D MINIMUM RATE D MINIMUM RATE D MAXIMUM RATE D MINIMUM RATE D MAXIMUM RATE D MINIMUM RATE D SYSTEM TYPE Select from list BOILER PRIORITY 3 TIMES Not used TIMES CIRCULATORS Circulator 1 Circulator 2 CIRCULATOR Circulator 1 Circulator 3 CIRCULATORS Circulator 1 Circulator 3 CIRCULATOR EXERCISING Circulator 1 Circulator 3 Circulator 1 Circulator 3 D Circulator 1 Circulator 3 D Circulator 1 Circulator 3 D Circulator 1 Circulator 3			Postpump Time:	
BOILER PRIORITY 2 MAXIMUM RATE D BOILER PRIORITY 2 Select from list D Baseboard (Finned tube or cast iron) TIMES Max Supply Min Supply Max OD Reset Modulate On Diff Modulate Off Diff D TIMES TIMES Max OT Time Boost Interval Prepump Time: D CIRCULATORS Circulator 1 Circulator 3 OFF SYSTEM TYPE Select from list D Max OD Reset Min On Time Boost Interval Prepump Time: D CIRCULATORS Circulator 1 Circulator 2 Circulator 3 ON MAXIMUM RATE D SYSTEM TYPE Select from list D MAXIMUM RATE D ON BOILER PRIORITY 3 TEMPERATURES Max Supply Min		CIRCULATORS	Circulator 1	ON
MAXIMUM RATE D MINIMUM RATE D SYSTEM TYPE Select from list FTB or CIB SYSTEM TYPE Select from list D Baseboard TEMPERATURES Max OD Reset Modulate On Diff Modulate On Diff D Baseboard TIMES Max On Time Proump Time: D Circulator 1 Circulator 1 OFF Circulator 2 ON ON MAXIMUM RATE D D Propump Time: D D Propump Time: D D VIMINIMUM RATE D D MINIMUM RATE D D VIMINIMUM RATE D D MINIMUM RATE D D MINIMUM RATE D D VIMINIMUM RATE D D MINIMUM RATE D D MINIMUM RATE D D MINIMUM RATE D D MINIMUM RATE D D BOILER PRIVERITY 3 MAXIMUM RATE D Not used TIMES Select from list D Circulator 1 D D D Circulator 2 D D D Modulate Off Diff D			Circulator 3	OFF
MINIMUM RATE D SYSTEM TYPE Select from list FTB or CIB SYSTEM TYPE Select from list Max Supply Max OD Reset Min OD Reset Min OD Reset D(70F) or as req.d Baseboard (Finned tube or cast iron) TIMES Max On Time Boost Interval Prepump Time: Postpump Time:		MAXIMUM RATE		D
BOILER PRIORITY 2 SYSTEM TYPE Select from list FTB or ClB BOILER PRIORITY 2 TEMPERATURES Max Supply Min Supply Min OD Reset Modulate On Diff Modulate Of Diff 180 F Baseboard (Finned tube or cast iron) TIMES Max On Time Boost Interval Prepump Time: Postpump Time: Postpump Time: D D CIRCULATORS Circulator 1 Circulator 2 Circulator 3 OFF MAXIMUM RATE D Modulate On Diff Modulate OF Diff D FIMES Select from list D FIMES Select from list D FIMES Circulator 1 Circulator 2 ON MAXIMUM RATE D MINIMUM RATE D SYSTEM TYPE Select from list D TEMPERATURES Max Supply Min Supply Min Supply D Modulate Off Diff D D Min On Time Modulate Off Diff D TIMES Min On Time Boost Interval Prepump Time: D D CIRCULATORS Circulator 1 Circulator 2 D CIRCULATORS Circulator 1 Circulator 3 D MAXIMUM RATE D D Min MAXIMUM RATE D Min On Time D Circulator 1 D Circulator 3 D		MINIMUM RATE		D
BOILER PRIORITY 2 TEMPERATURES Max Supply Min Supply Min OD Reset Min OD Reset Modulate Of Diff D D (70F) or as req'd D (0F) or		SYSTEM TYPE	Select from list	FTB or CIB
BOILER PRIORITY 2 TEMPERATURES Min Supply Max OD Reset Modulate On Diff Modulate On Diff Modulate Off Diff D (DF) or as reqid D			Max Supply	180 F
BOILER PRIORITY 2 TEMPERATURES Max OD Reset Modulate On Diff Modulate Of Diff D (top) of as red d D (0F) of a			Min Supply	D (70E) or on rog/d
BOILER PRIORITY 2 Modulate On Diff Modulate Off Diff D Baseboard (Finned tube or cast iron) TIMES Max On Time Boost Interval Prepump Time: Postpump Time: D D Circulator 1 OFF Circulator 2 ON Min Non Time D Maximum Rate D Min Supply D Max Supply D Max On Time D SYSTEM TYPE Select from list BOILER PRIORITY 3 TEMPERATURES Not used TIMES Min On Time D Min On Time D Modulate Off Diff D Min On Time D Modulate Off Diff D Max Supply D Max OD Reset D Min On Time D Boost Interval Prepump Time: D CIRCULATORS Circulator 1 D Circulator 2 D MaxIMUM RATE D Min On Time D Modulate Off Diff D Circulator 3 D Circulator 4 D		TEMPERATURES	Min OD Reset	D (0F) or as reg'd
BOILER PRIORITY 2 Modulate Off Diff D Baseboard (Finned tube or cast iron) TIMES Max On Time Boost Interval Prepump Time: Postpump Time: D D CIRCULATORS Circulator 1 Circulator 2 Circulator 3 OFF ON ON MAXIMUM RATE D MINIMUM RATE D MINIMUM RATE D SYSTEM TYPE Select from list D Max OD Reset D Min OD Reset D Min OD Reset D Modulate Off Diff D TIMES Min On Time SySTEM TYPE D BOILER PRIORITY 3 TIMES Min On Time Boost Interval Prepump Time: D D TIMES TIMES Min On Time Boost Interval Prepump Time: D D CIRCULATORS Circulator 1 Circulator 2 Circulator 3 D MAXIMUM RATE D D MINIMUM RATE D D MINIMUM RATE D D MINIMUM RATE D D CIRCULATOR EXERCISING Circulator 1 Circulator 2 Circulator 3 D Circulator 1 Circulator 2 D D Circulator 1 <th></th> <th></th> <th>Modulate On Diff</th> <th>D</th>			Modulate On Diff	D
Baseboard (Finned tube or cast iron) TIMES Max On Time Boost Interval Prepump Time: Postpump Time: D CIRCULATORS Circulator 1 Circulator 2 Circulator 3 ON MAXIMUM RATE D MINIMUM RATE D MINIMUM RATE D SYSTEM TYPE Select from list D SYSTEM TYPE Select from list D Max OD Reset D Max OD Reset D Min OD Reset D Min Out of Diff D Not used TIMES Min On Time Sost Interval Prepump Time: D CIRCULATORS Circulator 1 Circulator 2 Circulator 3 D Min Non Time Boost Interval Prepump Time: D Min Non Time Circulator 3 D Min Non Time Circulator 3 D Min On Time D D Circulator 1 D Circulator 2 D MINIMUM RATE D Circulator 1 D Circulator 2 D Circulator 3 D	BOILER PRIORITY 2		Modulate Off Diff	D
Baseboard (Finned tube or cast iron) TIMES Min On Time Boost Interval Prepump Time: Dostpump Ti			Max On Time	D
(Finned tube or cast iron) INNES Boost Interval Prepump Time: Postpump Time: Circulator 1 D CIRCULATORS Circulator 1 Circulator 2 ON MAXIMUM RATE D MINIMUM RATE D MINIMUM RATE D SYSTEM TYPE Select from list D SYSTEM TYPE Select from list D BOILER PRIORITY 3 TEMPERATURES Max Supply Min OD Reset Modulate Off Diff D Not used TIMES Min On Time Boost Interval Prepump Time: D CIRCULATORS Circulator 1 Circulator 2 D MAXIMUM RATE D D MAXIMUM RATE D D CIRCULATOR EXERCISING Circulator 1 Circulator 2 Circulator 3 D Circulator 1 D D Circulator 2 D D Circulator 3 D D	Baseboard	TIMES	Min On Time Reast Interval	D
Postpump Time: D CIRCULATORS Circulator 1 Circulator 2 Circulator 3 OFF MAXIMUM RATE D MINIMUM RATE D SYSTEM TYPE Select from list D SYSTEM TYPE Select from list D MAXIMUM RATE D Max Supply D Max OD Reset D Max OD Reset D Modulate On Diff D Max OD Reset D Modulate Off Diff D Min OD Time D Not used TIMES Min On Time D CIRCULATORS Circulator 1 D D CIRCULATOR EXERCISING Circulator 1 D D Girculator 1 D D D Circulator 3 D D D Circulator 1 D D D Circulator 3 D D D Circulator 3 D D D Circulator 1 D D D Circulator 3 D D D Circulator 3 D D <th>(Einned tube or cast iron)</th> <th>TIMES</th> <th>Prepump Time:</th> <th>D</th>	(Einned tube or cast iron)	TIMES	Prepump Time:	D
CIRCULATORS Circulator 1 Circulator 2 Circulator 3 OFF ON MAXIMUM RATE D MINIMUM RATE D SYSTEM TYPE Select from list D SYSTEM TYPE Select from list D BOILER PRIORITY 3 TEMPERATURES Max Supply Min OD Reset Modulate Off Diff D Not used TIMES Min On Time Boost Interval Prepump Time: D CIRCULATORS Circulator 1 Circulator 2 Circulator 3 D MAXIMUM RATE D D MINIMUM RATE D D CIRCULATOR EXERCISING Circulator 1 Circulator 2 Circulator 3 D Circulator 1 Circulator 3 D D Circulator 3 D D Circulator 1 Circulator 3 D D			Postpump Time:	D
CIRCULATORS Circulator 2 Circulator 3 ON MAXIMUM RATE D MINIMUM RATE D SYSTEM TYPE Select from list D SYSTEM TYPE Select from list D Max Supply Min Supply D Max OD Reset D Max OD Reset D Modulate On Diff D Modulate Off Diff D Not used TIMES Min On Time Boost Interval Prepump Time: D CIRCULATORS Circulator 2 Circulator 2 D MINIMUM RATE D D Circulator 1 D D Circulator 3 D D Circulator 1 D D Circulator 3 D D MINIMUM RATE D D Circulator 3 D D Circulator 3 D D Circulator 3 D D Circulator 3 D D MAXIMUM RATE D D Circulator 3 D D Circulator 3 D D			Circulator 1	OFF
MAXIMUM RATE D MINIMUM RATE D SYSTEM TYPE Select from list D SYSTEM TYPE Select from list D TEMPERATURES Max Supply Min Supply Max OD Reset D BOILER PRIORITY 3 TIMES Min On Time Boost Interval Prepump Time: D CIRCULATORS Circulator 1 D CIRCULATOR EXERCISING Circulator 1 D Circulator 1 D D Circulator 2 D Circulator 3 D		CIRCULATORS	Circulator 2	ON
MAXIMUM RATE D MINIMUM RATE D SYSTEM TYPE Select from list D SYSTEM TYPE Select from list D Min Supply Min Supply D Min OD Reset D Min OD Reset D Modulate Off Diff D Min On Time D BOILER PRIORITY 3 TIMES Not used TIMES CIRCULATORS Circulator 1 CIRCULATORS Circulator 2 MINIMUM RATE D MINIMUM RATE D MINIMUM RATE D Circulator 1 D Circulator 2 D Circulator 3 D Circulator 3 D Circulator 1 D Circulator 3 D			Circulator 3	
BOILER PRIORITY 3 SYSTEM TYPE Select from list D BOILER PRIORITY 3 TEMPERATURES Max Supply Min Supply Max OD Reset Modulate On Diff D BOILER PRIORITY 3 TIMES Min On Time Boost Interval Prepump Time: D D CIRCULATORS Circulator 1 Circulator 2 Circulator 3 D CIRCULATOR EXERCISING Circulator 1 Circulator 2 Circulator 3 D CIRCULATOR EXERCISING Circulator 1 Circulator 3 D				D
BOILER PRIORITY 3 Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff D BOILER PRIORITY 3 TIMES Min On Time Boost Interval Prepump Time: D D CIRCULATORS Circulator 1 Circulator 2 Circulator 3 D CIRCULATOR EXERCISING Circulator 1 Circulator 2 Circulator 1 D CIRCULATOR EXERCISING Circulator 1 Circulator 1 Circulator 1 D		SYSTEM TYPE	Select from list	D
BOILER PRIORITY 3 Min Supply D BOILER PRIORITY 3 TEMPERATURES Min OD Reset D Modulate Of Diff D Min OD Reset D BOILER PRIORITY 3 TIMES Min On Time D Not used TIMES Min On Time D CIRCULATORS Circulator 1 D CIRCULATOR EXERCISING Circulator 1 D Circulator 1 D D Circulator 2 D D Circulator 3 D Circulator 2 Circulator 1 D D Circulator 2 D D Circulator 3 D Circulator 3	\backslash	0.0.1	Max Supply	D
BOILER PRIORITY 3 TEMPERATURES Max OD Reset Min OD Reset Modulate On Diff Modulate On Diff D BOILER PRIORITY 3 TIMES Min On Time Boost Interval Prepump Time: D D CIRCULATORS Circulator 1 Circulator 2 Circulator 3 D MINIMUM RATE D CIRCULATOR EXERCISING Circulator 1 Circulator 2 Circulator 3 D CIRCULATOR EXERCISING Circulator 1 Circulator 2 Circulator 3 D			Min Supply	D
BOILER PRIORITY 3 Min OD Reset D Not used TIMES Min On Time D TIMES Min On Time D Prepump Time: D Postpump Time: D CIRCULATORS Circulator 1 MINIMUM RATE D MINIMUM RATE D Circulator 1 D Circulator 2 D Circulator 3 D Circulator 1 D Circulator 2 D Circulator 1 D Circulator 1 D Circulator 2 D Circulator 3 D		TEMPERATURES	Max OD Reset	D
BOILER PRIORITY 3 Not used TIMES Min On Time Boost Interval Prepump Time: Postpump Time: D CIRCULATORS Circulator 1 Circulator 2 MINIMUM RATE MINIMUM RATE Circulator 1 Circulator 2 Circulator 2 Circulator 3 D Circulator 1 Circulator 2 Circulator 1 Circulator 2 Circulator 1 Circulator 2 D Circulator 1 D Circulator 1 D Circulator 2 D Circulator 1 D Circulator 1 D Circulator 1			MIN OD Reset Modulate On Diff	
BOILER PRIORITY 3 Not used TIMES Min On Time Boost Interval Prepump Time: Postpump Time: CIRCULATORS Circulator 1 Circulator 2 Circulator 3 MAXIMUM RATE D MINIMUM RATE D Circulator 1 Circulator 2 Circulator 2 D CIRCULATOR EXERCISING Circulator 1 Circulator 2 Circulator 3 D Circulator 1 Circulator 1 D Circulator 1 D Circulator 1 D			Modulate Off Diff	D
Not used TIMES Min On Time Boost Interval Prepump Time: Postpump Time: D CIRCULATORS Circulator 1 Circulator 2 Circulator 3 D MAXIMUM RATE D MINIMUM RATE D Circulator 1 Circulator 2 Circulator 3 D Circulator 1 Circulator 3 D Circulator 1 Circulator 2 Circulator 2 D Circulator 1 Circulator 2 Circulator 3 D	BOILER PRIØRITY 3			
Not used IIMES Boost Interval D Prepump Time: D Postpump Time: D CIRCULATORS Circulator 1 MAXIMUM RATE D MINIMUM RATE D Circulator 1 D Circulator 2 D Circulator 3 D Circulator 1 D Circulator 2 D Circulator 3 D Circulator 1 D Circulator 2 D Circulator 3 D Circulator 1 D	Х		Min On Time	D
CIRCULATOR EXERCISING Circulator 1 Circulator 2 Circulator 2 Circulator 3 Circulator 1 Circulator 3 Circulator 1 Circulator 1 Circulator 1 Circulator 1 Circulator 2 Circulator 2 Circulator 2 Circulator 1 Circulator 2 Circulator 3 D	Not used	TIMES	Boost Interval	
CIRCULATORS CICulator 1 CIRCULATORS Circulator 2 Circulator 3 Circulator 3 Circulator 3 Circulator 1 Circulator 1 Circulator 2 Circulator 2 Circulator 3 Circulator 1 Circulat			Postpump Time:	D
CIRCULATORS Circulator 2 D Circulator 3 D MAXIMUM RATE D MINIMUM RATE D Circulator 1 D Circulator 2 D Circulator 2 D Circulator 3 D D Circulator 1 D Circulator 1 D Circulator 1 D			Circulator 1	D
Circulator 3 D MAXIMUM RATE D MINIMUM RATE D Circulator 1 D Circulator 2 D Circulator 3 D		CIRCULATORS	Circulator 2	D
MAXIMUM RATE D MINIMUM RATE D CIRCULATOR EXERCISING Circulator 1 Circulator 2 D Circulator 3 D Circulator 1 D			Circulator 3	D
CIRCULATOR EXERCISING Circulator 1 Circulator 2 Circulator 3 Circulator 1	/			D
CIRCULATOR EXERCISING Circulator 2 Circulator 3 Circulator 1	/			D
Circulator 3 D Circulator 1 D	CIRCULATOR EXERCISING	Circulator 1		ם ו
Circulator 1 D		Circulator 3		D
		Circulator 1		D
FKEEZE PRUIEUI UIKUS Circulator 2 D Circulator 3 D	FREEZE PRUTECT CIRCS	Circulator 2 Circulator 3		D



LEGEND

J.M

\star = Supplied by installer

- 1 DHW circulator *
- 2 BOILER circulator (shipped loose with boiler)
- 3 Baseboard circulator ★
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- 6 Baseboard thermostat *
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- **10** Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- **11** Low water cutoff (if used) *****
- 21 Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves ★
- 24 Air separator with automatic air vent *
- **25** Diaphragm-type expansion tank *****
- **26** Fresh water supply install per applicable codes *****
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *****
- **30** Boiler relief valve (install per boiler manual)





Multi-zone BASEBOARD (Zone valves) | Multi-zone RADIANT (Zone valves) | DHW (Direct-connected) (Radiant load must be <30% of total heat loss)

Purpose

- Space heating with multiple baseboard (finned tube or cast iron) zones and multiple radiant zones, zoning with zone valves.
- The radiant load must be no more than 30% of the total heating load to use the control strategy of this application. Alternatively, see Application 7a, which does not limit load sizes.
- DHW piped directly to the boiler.
- DHW priority space heating is disabled during call for heat from water heater.

U-Control setting notes

- See the table at right for required and optional settings.To see the navigation sequence to access the BOILER SETTINGS
- and SYSTEM ŠETTINGS menus, see page 7.
 Select DHW DIRECT for the DHW BOILER PRIORITY 1. This informs the control that the DHW tank is directly connected to the boiler.

Circulators and piping

• Piping must be primary/secondary as shown.

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently see boiler manual and other applications in this guide.
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

BASEBOARD

- Multiple zones using zone valves.
- Size circulator for required flow.
- Baseboard circulator and zone valves supplied by installer.

RADIANT

• Multiple zones using zone valves. Radiant load must be less than 30% of total heat loss.

NOTICE

See **Application 7a**, page 22, for radiant heating using independent temperature control for the radiant zone, with no limit to the radiant load.

 Size circulator for required flow. Radiant circulator and zone valves supplied by installer.

BOILER

- See boiler manual for sizing.
- · Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

- Connect field wiring as shown on next page.
- Zone valve end switches and DHW aquastat activate the U-Control. The U-Control activates the circulators for DHW and radiant circuits.
- This application applies only to multiple-zone space heating, using Weil-McLain zone controller.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each if load is higher, provide a circulator relay or contactor for circulator power.
- Provide a Weil-McLain WMR-21 relay to operate baseboard circulator.

U-CONTROL SET (SEE NAVIGATION FLOW BE	TTINGS XXX ELOW) D	— VALUE MUST BE SET (C — DEFAULT ACCEPTABLE;	DR VERIFIED) AS INDICATED CHANGE ONLY IF DESIRED
	BOILER SE	TTINGS	
BOILER MODEL		Verify model n	umber is correct
HIGH ALTITUDE		Set to YES if	high altitude
HIGH LIMIT)
WWSD TEMP		DEFAULT (70 °F	OR AS REQUIRED
ADJUST OUTDOOR		DEFAULT (0 °F)	OR AS REQUIRED
ADD'L HEAT DEMAND TYPE		Тур	be 1
ADD'L HEAT DEMAND TIME		DEFAULT (0	minutes)
	SYSTEM SE	TTINGS	
	SYSTEM TYPE	Soloot from list	DHW Direct
	STSTEMTTE	Max Supply	190 F
	TEMPERATURES	Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D
BOILER PRIORITY 1		Max On Time	D (30 minutes)
DHW	TIMES	Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	ON OFF OFF
	MAXIMUM RATE		D
	SYSTEM TYPE	Select from list	ETB or CIB
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	180 F D D (70F) or as req'd D (0F) or as req'd D D
Baseboard (Finned tube or cast iron)	TIMES	Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D (30 minutes) D D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF
	MAXIMUM RATE		D
	SYSTEM TYPE	Select from list	Note 1 (at left)
<i>BOILER PRIORITY 3</i> Radiant zones	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	As required D D (70F) or as req'd D (0F) or as req'd D D
Note 1 — Select system type: RSG = Slab on grade	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D D
RSU = Below floor RAF = Above floor	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON ON
	MAXIMUM RATE		D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		D D D D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2		D D

Circulator 3



LEGEND

J.M

***** = Supplied by installer

- DHW circulator *
- BOILER circulator (shipped loose with boiler)
- Radiant circuit circulator *
- 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- Baseboard zone valve end switches *
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- DHW tank aquastat *
- **10** Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- 14 Radiant zone valve end switches *
- **15** Weil-McLain WMR-21 relay *
- 16 Baseboard circuit circulator *
- 21 Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves *
- 24 Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- 26 Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)
- 34 Zone valves *
- 35 Bypass pressure regulator *





Single-zone BASEBOARD | Single-zone RADIANT | POOL Heat exchanger (Radiant load must be <30% of total heat loss)

Purpose

- Single zone of radiant, single zone of baseboard (finned tube or cast iron) and single zone for pool heat exchanger. This application can be adapted for multiple zones if piping components and controls are added to control the zone circulators or zone valves and provide a call for heat signal to the U-Control.
- Zoning with circulators.

U-Control setting notes

System type DHW SYSTEM is used for BOILER PRIORITY 3, the WMPH zone. This prevents outdoor reset regulation of the supply water temperature to the pool heater.

Circulators and piping

Piping must be primary/secondary as shown.

BASEBOARD

- Single zone. Multiple zones can be used if zone controller and piping components are added.
- Size circulators for required flow.
- Baseboard circulators supplied by installer.

RADIANT

Single zone. Multiple zones can be used if zone controller and piping components are added.

See Application 7a, page 22, for radiant heating NOTICE using independent temperature control for the radiant zone, with no limit to the radiant load.

Size circulators for required flow. Radiant circulators supplied by installer.

HEAT EXCHANGER

- Size circulator for required flow.
- Typical application shown using Weil-McLain pool heat exchanger (WMBP).
- Heat exchanger and circulator supplied by installer.

BOILER

- See boiler manual for sizing.
- Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

- Connect field wiring as shown on next page.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each — if load is higher, provide a circulator relay or contactor for circulator power.
- Provide a Weil-McLain WMR-21 relay to operate boiler circulator.

U-CONTROL SET (SEE NAVIGATION FLOW BE	TTINGS XXX ELOW) D	— VALUE MUST BE SET (C — DEFAULT ACCEPTABLE; (R VERIFIED) AS INDICATED CHANGE ONLY IF DESIRED
	BOILER SE	TTINGS	
BOILER MODEL		Verify model nu	mber is correct
HIGH ALTITUDE		Set to YES if	high altitude
HIGH LIMIT		0)
WWSD TEMP		DEFAULT (70 °F)	OR AS REQUIRED
ADJUST OUTDOOR		DEFAULT (0 °F)	OR AS REQUIRED
ADD'L HEAT DEMAND TYPE		Тур	be 1
ADD'L HEAT DEMAND TIME		DEFAULT (0	minutes)
	SYSTEM SE	TTINGS	
	SYSTEM TYPE	Select from list	FTB or CIB
RΛΙΙ ΕΒ ΒΒΙΛΒΙΤΥ 1	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	180 F D D (70F) or as req'd D (0F) or as req'd D D
		Max On Time	D
Baseboard (Finned tube or cast iron)	TIMES	Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	ON ON OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
	SYSTEM TYPE	Select from list	Note 1 (at left)
<i>BOILER PRIORITY 2</i> Radiant zone	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	As required D (70F) or as req'd D (0F) or as req'd D D
Note 1 — Select system type: RSG = Slab on grade	TIMES	Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
RSU = Below floor RAF = Above floor	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF
	MAXIMUM RATE		D
	MINIMUM RATE	Output (D
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	190 F D D D D D D D D D
<i>BOILER PRIORITY 3</i> WMPH zone	TIMES	Min On Time Boost Interval Prepump Time:	D D D D
	CIRCULATORS	Postpump Time: Circulator 1 Circulator 2 Circulator 3	D OFF ON ON
			D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		D D D D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3		D D D



LEGEND ***** = Supplied by installer 1 BASEBOARD circulator * 2 BOILER circulator (shipped loose with boiler) 3 POOL HEAT EXCHANGER circulator * 120VAC power supply, 15-amp minimum rating 4 5 U-Control Baseboard zone thermostat * 6 7 Supply temperature sensor - strap to supply line Return temperature sensor - strap to return line 8 Outdoor temperature sensor (supplied with boiler; install if U-Control will 10 be set for outdoor reset operation) 11 Low water cutoff (if used) * 14 Radiant zone thermostat * 15 Weil-McLain WMR-21 relay * 16 RADIANT circulator * 18 Pool heater aquastat * 21 Ultra boiler

M

- 23 Flow/check valves *
- 24 Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- **26** Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)





Single or Multi-zone SPACE HEATING | DHW (Direct-connected) | ISOLATION Heat exchanger (Tall buildings) (Use where space heating system operating pressure is over 25 PSIG)

Purpose

- Isolation heat exchanger for applications with high system pressure (over 25 PSIG), such as tall buildings. Typical application shown using Weil-McLain WMBP brazed-plate exchanger.
- Space heating via hot water feed to building terminal units.
- Space heating circulator and heat exchanger primary circulator are activated on call for heat by the heating system.
- DHW piped directly to the boiler.
- DHW priority space heating and heater exchanger heating are disabled during call for heat from water heater.

U-Control setting notes

- See the table at right for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.
- Select DHW DIRECT for the DHW BOILER PRIORITY 1. This informs the control that the DHW tank is directly connected to the boiler.

Circulators and piping

• Piping must be primary/secondary as shown.

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping — see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently — see boiler manual and other applications in this guide.
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

HEAT EXCHANGER

- Size circulator for required flow and pressure drop.
- Heat exchanger, piping components and circulator supplied by installer (except the boiler circulator, shipped loose with the boiler).

SPACE HEATING

- Size circulator for required flow and pressure drop.
- Terminal units, piping components and circulator supplied by installer.

BOILER

- See boiler manual for sizing.
- Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

- Connect field wiring as shown on next page.
- Provide Weil-McLain WMR-21 relay to operate space heating circulator.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each if load is higher, provide a circulator relay or contactor for circulator power.
- DO NOT connect the outdoor sensor to the U-Control unless the water supply to the heat exchanger is to be reset based on outdoor temperature.

U-CONTROL SET (SEE NAVIGATION FLOW BE	TTINGS XXX ELOW) D	— VALUE MUST BE SET (C — DEFAULT ACCEPTABLE; (R VERIFIED) AS INDICATED CHANGE ONLY IF DESIRED
	BOILER SE	TTINGS	
BOILER MODEL		Verify model nu	mber is correct
HIGH ALTITUDE		Set to YES if	high altitude
HIGH LIMIT)
WWSD TEMP		DEFAULT (70 °F)	OR AS REQUIRED
ADJUST OUTDOOR		DEFAULT (0 °F)	OR AS REQUIRED
ADD'L HEAT DEMAND TYPE		[)
ADD'L HEAT DEMAND TIME)
	SYSTEM SE	TTINGS	
	SYSTEM TYPE	Select from list	DHW Direct
		Max Supply	190 F
	TEMPERATURES	Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D
BUILER PRIURITY 1		Max On Time	D
DHW	TIMES	Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	ON OFF OFF
			D
	SYSTEM TYPE	Select from list	CUS
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	190 F 190 F D D D
<i>BOILER PRIORITY 2</i> Heat exchanger	TIMES	Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON ON
	MAXIMUM RATE		D
\ /	SYSTEM TYPE	Select from list	D
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D D
BUILER PRIORITY 3 Not used	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
/			0
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		D D D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2		D D

Circulator 3



LEGEND

M

***** = Supplied by installer

- 1 DHW circulator *
- 2 BOILER circulator (shipped loose with boiler)
- 3 HEAT EXCHANGER PRIMARY circulator *
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- 10 Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- 14 Space heating thermostat or call for heat contact *
- 15 Weil-McLain WMR-21 relay *
- **16** SPACE HEATING circulator *
- 21 Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves *
- 24 Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- **26** Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- 29 Secondary piping connection for boiler loop *
- **30** Relief valves boiler (install per boiler manual) and heat exchanger space heating side





Multiple boiler operation options

Using the U-Control settings

ADDITIONAL HEAT DEMAND

BOILER SETTINGS				
BOILER MODEL				
HIGH ALTITUDE				
HIGH LIMIT				
WWSD TEMP				
ADJUST OUTDOOR				
ADD'L HEAT DEMAND TYPE				
ADD'L HEAT DEMAND TIME				

- 1. The ADD'L HEAT DEMAND settings (the two red boxes above) are for multiple boilers or multiple heating sources (an Ultra boiler collaborating with a heat pump or a different boiler, for examples).
 - **NOTICE** Additional heat demand **DOES NOT PASS ON** if the system type is DHW Direct or Custom. Do not use this setting on any boiler unless it is the last in the lead/ shadow sequence.

ADDITIONAL HEAT DEMAND settings

OFF

1. Function disabled — NO signal would be passed on to other boilers.

Type 1

- 1. This means the Ultra boiler is the primary heat source.
 - When the Ultra boiler receives a call for heat, it begins its startup sequence and also starts a delay timer (set as ADD'L HEAT DE-MAND TIME).
 - b. When the ADD'L HEAT DEMAND TIME has elapsed, the U-Control closes the "Additional heat demand contact," terminals P16–6 & 7.
 - c. Use P16–6 & 7 to start the next heat source.
 - d. If the next heat source is an Ultra boiler, connect from the first boiler's P16–6 & 7 terminals to the second boiler's "Heat demand 1" terminals (P11–4 and 5).
 - e. Program the second boiler's ADD'L HEAT DEMAND TIME to start a third boiler the same way, and so on to sequentially fire multiple boilers.

Type 2

- 1. This means the boiler is the secondary heat source.
 - a. When the U-Control receives a call for heat, it immediately activates the "Additional heat demand contact," terminals P16– 6 & 7. This contact is used to start the next heat source immediately.
 - b. When the ADD'L HEAT DEMAND TIME has elapsed, the Ultra boiler begins its startup sequence and continues to heat until the demand is satisfied.
 - c. Type 2 assignment would generally only be used if the other heat source is a different boiler or a heat pump, for example.

Type 3

- 1. This assigns the boiler as the LEAD boiler in a multiple boiler system.
 - a. The LEAD boiler must have system supply and return sensors mounted on the system supply and return pipes and wired to the boiler. An outdoor sensor must also be installed if outdoor reset is desired.
 - b. When the U-Control receives a call for heat, it begins its heating sequence and starts the ADD'L HEAT DEMAND TIME delay timer.
 - c. When the ADD'L HEAT DEMAND TIME has elapsed, the U-Control sends a 0–10 VDC proportional signal out its 0–10 VDC output terminals, P16–1 & 2.
 - d. Additional Ultra boilers are called SHADOW boilers.
 - e. Connect the LEAD boiler output terminals (P16–1 & 2) to the first SHADOW boiler's 0–10 VDC input terminals, P15–5 & 6.
 - f. For the LEAD boiler and all additional boilers except the last SHADOW boiler, connect P16–1 & 2 of each boiler to P15–5 & 6 of the next boiler.
 - g. Each SHADOW boiler will start and modulate based on the 0-10 VDC signal from the previous boiler.
 - h. The SHADOW boilers must be set up as Type 4 (see below). They do not need their ADD'L HEAT DEMAND TIME values to be set.

Type 4

- 1. This assigns the boiler as a SHADOW boiler in a multiple boiler system.
 - a. For Type 4 boilers, the ADDITIONAL HEAT DEMAND function only applies to the Priority 1 system.
 - b. Wire the boilers as explained under Type 3, above.
 - c. Each SHADOW boiler must have system supply and return sensors mounted on the system supply and return pipes and wired to the boiler. An outdoor sensor must also be installed if outdoor reset is desired.



Multiple boiler operation options (continued)

Using the U-Control settings

SENSORS

- 1. Each Ultra boiler is shipped with three remote-mounted sensors supply, return and outdoor. Supply and return sensors are strap-on type.
 - a. **Supply sensor** Every boiler must have its supply sensor attached to the system supply piping. It must sense the temperature of the water going to the system. (The boiler has an integral sensor that monitors boiler outlet water temperature.) the LEAD boiler adjusts firing rate as needed to maintain system supply temperature. Shadow boilers modulate according to the 0–10 VDC signal from the lead boiler, but they turn on and off based on system supply temperature.
 - b. **Return sensor** Every boiler must have its supply sensor attached to the system return piping to allow the boiler to monitor temperature rise through the boiler.
 - c. **Outdoor sensor** Install an outdoor sensor for each boiler if the multiple boiler system will use outdoor reset.

NOTICE

The description of each multiple boiler application in this guide indicates which sensors are required to accomplish the intent of the application.

ADDITIONAL HEAT DEMAND applications

Type 1 and Type 2 applications

- 1. **Application 17a Multiple heat sources** applies this option to delay operation of the Ultra boiler, allowing time for the primary heat source to satisfy the call for heat from the thermostat, end switches, etc.
 - a. The Ultra boiler is setup as Type 2.
 - b. When the room thermostat calls for heat at the Ultra boiler, the U-Control immediately closes the contact across P16 terminals 6 and 7.
 - c. This contact is used to start the auxiliary heat source (wood stove, etc.)
 - d. The U-Control also immediately starts its ADD'L HEAT DEMAND TIME timer (set at 60 minutes for this application). If this timer elapses and the call for heat is still present, the Ultra boiler will fire.
 - e. The Ultra boiler will operate the boiler circulator and system circulator to provide heat to the baseboard units.
 - f. This application provides DHW using the Priority 2 functions of the Ultra boiler. With the Priority 1 MAX ON TIME set to 0, the Ultra boiler will immediately switch to DHW operation on any call from the DHW tank.
- 2. Other possible applications of Type 1/Type 2
 - a. **Application 17 Multiple heat sources** could be setup with the Ultra boiler specified as Type 2, with ADD'L HEAT DEMAND TIME set to 60 minutes, typically. The aquastat (item 14) near the heat exchanger outlet would not be used in this case. This setup would provide 60 minutes for the auxiliary heat source to satisfy demand before the Ultra boiler would fire for space heating. The Ultra boiler will always respond to a call for heat from the DHW tank.
 - *b.* **Combustion air heater** An Ultra boiler could be set as Type 2, with terminals P16–1 & 2 used to start a combustion air heater. Set the time delay to 10 minutes to allow time for combustion air heater to reach steady-state operation before the Ultra boiler fires.

Type 3 and Type 4 — Sequential operation

- 1. Sequential operation is achieved by setting a time delay between boiler start-ups. This method is used in:
 - a. Application 18 Multiple boilers
 - b. Application 19 Multiple boilers
 - c. Application 20 Multiple boilers
 - d. Application 21 Multiple boilers.
- 2. Use the ADD'L HEAT DEMAND TIME setting to delay activation of each successive boiler in a multiple boiler system.
 - a. When one of the boilers receives a call for heat, the U-Control starts the ADD'L HEAT DEMAND TIME timer. Only when this timer elapses is the signal to start passed on to the next boiler that is, after this time elapses, the U-Control sends a 0–10 VDC signal out of P16 terminals 1 and 2.
 - b. Typically, set the ADD'L HEAT DEMAND TIME to 5 minutes for all boilers except the last shadow boiler.
 - c. Wire each boiler with its P16-1 & 2 output terminals (0–10 VDC) going to the P15-5 & 6 terminals of the next boiler.
- 3. Staging of boilers can also be improved by the setting of each boiler's MODULATE ON and MODULATE OFF differentials, as explained below.
- 4. Set the SHADOW boilers' MODULATE ON DIFF and MODULATE OFF DIFF settings at different values to cause the SHADOW boilers to cycle at different system SUPPLY temperatures. This will improve the sequential firing of SHADOW boilers.
 - The applications in this guide use ON/OFF values of 5°F/10°F for the first SHADOW boiler and 10°F/5°F for the last SHADOW boiler.
 - For systems with more than three boilers, these values can be graduated to improve sequencing. Example: for four boilers, use MODULATE ON DIFF values of 3/6/9 and OFF DIFF values of 9/3/6.
 - **NOTICE** To effectively use outdoor reset, all SHADOW boilers must be have OUTDOOR sensors installed if the LEAD boiler is set up for outdoor reset operation. The MAX SUPPLY, MIN SUPPLY, MAX OD RESET and MIN OD RESET values must be set exactly as on the LEAD boiler.

DO NOT use outdoor sensors and outdoor reset on multiple boilers supplying a system that requires fixed high-temperature water, such as DHW applications with the water heaters piped in the system, not directly to one of the boilers.

NOTICE The modulating signal from U-Control P16 of one boiler to P15 of the next is polarity sensitive.

Connect wires + to + and – to – as shown. That is, P16–1 goes to P15–6 and P16–2 goes to P15–5.



Application 17 — Multiple heat sources

ALTERNATIVE HEAT SOURCE as primary / ULTRA as back-up | Single-zone BASEBOARD or FAN COIL DHW (Direct-connected)

Purpose

- The main heat source for this system is a wood-fired boiler or other alternative heat source. The Ultra boiler provides back-up heating. In addition, the Ultra boiler provides domestic hot water via an indirect water heater.
- Space heating is with baseboard, fan coils or other. This application can be adapted for multiple zones if piping components and controls are added to control the zone circulators or zone valves and provide a call for heat signal to the U-Control.
- DHW piped directly to the Ultra boiler.
- DHW priority space heating is disabled for the Ultra boiler during call for heat from the water heater.

Circulators and piping

Piping must be primary/secondary as shown.

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently see boiler manual and other applications in this guide.
- U-Control is set for DHW priority space heating will be discontinued during a call for DHW.

BASEBOARD

 Size circulator for required flow. The circulator must be selected to handle the head loss through the heat exchanger in addition to the system heat losses.

ALTERNATIVE HEAT SOURCE

- Provide a heat source (such as a wood-fired boiler, solar heat system, etc.) with all controls and piping (per manufacturer's instructions). A circulator must be supplied in the heat source piping.
- HEAT SOURCE, associated piping and components, and all circulators (except the boiler circulator) supplied by installer.
- Select a heat exchanger for the required load. Use a shell and tube exchanger as shown in the piping diagram. A brazed-plate exchanger can be used, but only if the HEAT SOURCE system is closed.
- If more suited to the application, swap the shell side and tube side of the exchanger versus the piping diagram.

ULTRA BOILER

- See boiler manual for sizing.
- · Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

- · Connect field wiring as shown on next page.
- Provide a Weil-McLain WMCR-2 circulator zone controller to operate the baseboard system circulator and provide call for heat to alternative heat source and the Ultra boiler.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each if load is higher, provide a circulator relay or contactor for circulator power.
- Provide and install an aquastat in the supply line from the heat exchanger as shown. This aquastat will activate the Ultra boiler if the supply water temperature falls below the aquastat setting.

U-CONTROL SETTINGS
(SEE NAVIGATION FLOW BELOW)

- VALUE MUST BE SET (OR VERIFIED) AS INDICATED - DEFAULT ACCEPTABLE; CHANGE ONLY IF DESIRED

BOILER SETTINGS

XXX

BOILER MODEL	Verify model number is correct
HIGH ALTITUDE	Set to YES if high altitude
HIGH LIMIT	D
WWSD TEMP	DEFAULT (70 °F) OR AS REQUIRED
ADJUST OUTDOOR	DEFAULT (0 °F) OR AS REQUIRED
ADD'L HEAT DEMAND TYPE	D
ADD'L HEAT DEMAND TIME	D

		TIMAO	
	SYSTEM TYPE	Select from list	DHW Direct
		Max Supply	190 F
	TEMPERATURES	Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D
BOILER PRIORITY 1		Max On Time	D
DHW	TIMES	Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	ON OFF OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
	SYSTEM TYPE	Select from list	FTB or FCL
RΛΙΙ ΕΒ ΒΒΙΛΒΙΤΥ 2	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	180 F D D (70F) or as req'd D (0F) or as req'd D D
Baseboard (Finned tube or cast iron)	TIMES	Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF
	MAXIMUM RATE		D
	MINIMUM RATE		D
\setminus /	SYSTEM TYPE	Select from list	D
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D D
BOILER PRIØRITY 3 Not used	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
	MAXIMUM RATE		D
/ \	MINIMUM RATE		D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		D D D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3		D D D



LEGEND

M

***** = Supplied by installer

- 1 DHW circulator *
- 2 BOILER circulator (shipped loose with boiler)
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- 6 Baseboard (or fan coil) thermostat *
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- **10** Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for warm weather shutdown)
- 11 Low water cutoff (if used) *
- 14 Aquastat in supply line from HEAT SOURCE piping *
- 15 Weil-McLain WMCR-2 circulator control *
- **16** System circulator *
- **21** Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves *
- **24** Air separator with automatic air vent *
- **25** Diaphragm-type expansion tank *
- 26 Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)
- 38 Alternative heat source and piping per mfr's instructions * (must include a circulator and all piping and components specified in manufacturer's instructions)
- 40 Isolation heat exchanger (DO NOT use a brazed-plate exchanger when connected to an open system) *





Application 17a — Multiple heat sources

NON-HYDRONIC PRIMARY HEAT SOURCE as Type 1 (LEAD) / ULTRA as Type 2 (BACKUP) Single-zone or multi-zone BASEBOARD or FAN COIL | DHW (Direct-connected)

Purpose

- The main heat source for this system is a non-hydronic heating unit, such as a wood-fired stove or warm-air furnace. The Ultra boiler provides back-up heating. In addition, the Ultra boiler provides domestic hot water via an indirect water heater.
- Space heating is with baseboard, fan coils or other. This application can be adapted for multiple zones if piping components and controls are added to control the zone circulators or zone valves and provide a call for heat signal to the U-Control.
- DHW piped directly to the Ultra boiler.
- DHW priority space heating is disabled for the Ultra boiler during call for heat from the water heater.

Circulators and piping

• Piping must be primary/secondary as shown.

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently — see boiler manual and other applications in this guide.
- U-Control Priority 1 MAX ON TIME is set to 0 minutes. The control will immediately switch to DHW heating on call from the DHW aquastat.
 - **BASEBOARD** Size circulator for required flow.
- The baseboard circulator must be supplied by the installer.

ALTERNATIVE HEAT SOURCE

• Provide a heat source (such as a wood-fired stove) with all controls needed, per manufacturer's instructions.

ULTRA BOILER

- See boiler manual for sizing.
- Circulator shipped loose with boiler.
- Boiler loop piping can be provided using optional Easy-Up Manifolds, available from Weil-McLain (see page 5).

Wiring

- Connect field wiring as shown on next page.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each if load is higher, provide a circulator relay or contactor for circulator power.
- Provide and install a room thermostat. The thermostat provides a call for heat to the Ultra boiler. The Ultra boiler is set as ADD'L HEAT DEMAND Type II — it will immediately pass the call for heat on to the alternative heat source. If the ADD'L HEAT DEMAND TIME elapses and the thermostat is still calling for heat, the Ultra boiler will come on and provide heat to the hydronic system.
 - **NOTICE** Set the Ultra boiler Priority 1 MAX ON TIME to 0 minutes. The boiler will immediately switch to DHW mode on call from the DHW aquastat.

U-CONTROL SET (SEE NAVIGATION FLOW BE	TINGS ELOW)	xxx D	— VALUE MUST BE SET (— DEFAULT ACCEPTABLE;	DR VERIFIED) AS INDICATE CHANGE ONLY IF DESIRED
	BOILE	R SE'	TTINGS	
			Verify model n	umber is correct
			Set to YES it	high altitude
HIGHLIMIT				D
WWSD TEMP			DEFAULT (70 °F	OR AS REQUIRED
ADJUST OUTDOOR			DEFAULT (0 °F)	OR AS REQUIRED
ADD'L HEAT DEMAND TYPE			Type 2 –	BACKUP
ADD'L HEAT DEMAND TIME			60 m	inutes
	OVOTE		TTINOC	
	5151E	M SE	TTINGS	
	SYSTEM TY	PE	Select from list	FTB or FCL
RNII FR PRINRITY 1	TEMPERAT	URES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	180 F D D (70F) or as req'd D (0F) or as req'd D D
			Max On Time	0 minutes
Baseboard	TIMES		Boost Interval	D
(Finned tube or cast iron)			Prepump Time:	D
			Circulator 1	OFF
	CIRCULATO	ORS	Circulator 2	ON
		ATE	Circulator 3	ON
				D
	SYSTEM TY	PE	Select from list	DHW Direct
			Max Supply	190 F
	TEMPERAT	URES	Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D
<i>Boiler Priority 2</i> DHW	TIMES		Max On Time Min On Time Boost Interval Prepump Time: Postnumn Time	D 60 minutes D D D
			Circulator 1	ON
	CIRCULATORS		Circulator 2	OFF
			Circulator 5	D
	MINIMUM R	ATE		D
\backslash /	SYSTEMTY	PE	Select from list	D
	TEMPERAT	URES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D D D
BOILER PRIØRITY 3 Not used	TIMES		Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATO	ORS	Circulator 1 Circulator 2 Circulator 3	D D D
/ \				D
,	Circulator 1	AIE		D
CIRCULATOR EXERCISING	Circulator 2 Circulator 3			D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2			D

Circulator 3



LEGEND

I

***** = Supplied by installer

- 1 DHW circulator *
- 2 BOILER circulator (shipped loose with boiler)
- 3 System (or zone) circulator *
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- 6 Room thermostat *
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- 10 Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for warm weather shutdown)
- 11 Low water cutoff (if used) *
- 21 Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves *
- 24 Air separator with automatic air vent *
- **25** Diaphragm-type expansion tank *
- **26** Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)
- **38** Alternative heat source, installed per mfr's instructions *

FIELD WIRING





Application 18 — Multiple boilers

Multiple Ultra boilers | Multiple-zone SPACE HEATING (Circulators with WMCR) | DHW (Direct-connected)

Purpose

- Space heating with multiple Ultra boilers and multi-zone space heating using baseboard, fan coils, or other (zoning with circulators).
- DHW piped directly to one boiler.
- DHW priority space heating and heater exchanger heating are disabled during call for heat from water heater.

Circulators and piping

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping - see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently - see boiler manual and other applications in this guide.
- Pipe the indirect water heater to the last SHADOW boiler. The U-Control on the last SHADOW boiler is set to immediately switch to DHW heating on call from the DHW aquastat. Set system type to DHW-DIRECT.

BASEBOARD or FAN COIL

- Multiple zones.
- Size circulators for required flow.
- Zoning circulators supplied by installer.

BOILER

- Ultra boiler piping must be primary/secondary as shown, with the boiler piped in a secondary loop and the DHW piped to the last SHADOW boiler.
- See boiler manual for sizing.
- Circulator shipped loose with each boiler.

Wiring

- Connect field wiring as shown on next page.
- This application applies only to multiple-zone space heating, using Weil-McLain zone controller.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each - if load is higher, provide a circulator relay or contactor for circulator power.
- Provide Weil-McLain WMCR circulator zone controller for zone circulators.
- Connect the DHW aquastat only to the last boiler in the series.

LEAD I	Boiler U-Co	ontrol setti	ngs
xxx D	- VALUE MUST BE SET (C	See SHADOW boiler settings on pages 50 and 51	
	BOILER SET	TINGS	
BOILER MODEL		Verify model nu	mber is correct
HIGH ALTITUDE		Set to YES if	high altitude
HIGH LIMIT		[)
WWSD TEMP		DEFAULT (70 °F)	OR AS REQUIRED
ADJUST OUTDOOR		DEFAULT (0 °F)	OR AS REQUIRED
ADD'L HEAT DEMAND TYPE		Type 3	– LEAD
ADD'L HEAT DEMAND TIME		5 mir	nutes
	SYSTEM SE	TTINGS	
	SYSTEM TYPE	Select from list	Select type used
ΡΛΙΙ ΕΡ ΡΡΙΛΡΙΤΥ 1	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	180 F or as req'd D (70F) or as reo'd D (0F) or as reo'd D or as reouired D D D
		Max On Time	D
Space heating (any type)	TIMES	Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF
	MAXIMUM RATE		D
\backslash		Calaat faam lint	D
	TEMPERATURES	Select from list Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff	
<i>BOILER PRIØRITY 2</i> Not used	TIMES	Modulate Off Diff Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
	MAXIMUM RATE		D
<u> </u>		Soloot from list	D
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate Of Diff Modulate Off Diff	
BOILER PRIØRITY 3 Not used	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
	MAXIMUM RATE		D
CIRCULATOR EXERCISING	MINIMUM RATE Circulator 1 Circulator 2 Circulator 3		D D D D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3		D



LEGEND

JA

***** = Supplied by installer

- 1 DHW circulator *
- 2 BOILER circulator (shipped loose with boiler)
- 3 Zone circulators *
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- 6 Zone thermostats *
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- 10 Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- 12 Weil-McLain WMCR circulator zone controller *
- **21** Ultra boiler
- 22 Indirect water heater *
- 23 Flow/check valves
- **24** Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- **26** Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- **29** Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)
- 40 Manifolds, Weil-McLain Easy-Fit shown *





Application 18 — Multiple boilers (continued)

Multiple Ultra boilers | Multiple-zone SPACE HEATING (Circulators with WMCR) | DHW (Direct-connected)

U-Control setting notes (LEAD boiler)

- Additional heat time is set to 5 minutes to delay start of next boiler in sequence enough to allow system to respond. Change this setting value if desired.
- See following pages for addition boiler setting information.



DO NOT set the LEAD boiler PRIORITY 1 SYS-TEM TYPE to Custom or DHW. Shadow boilers set to TYPE 4 will not work with these settings.

NOTICE The modulating signal from U-Control P16 of one boiler to P15 of the next is polarity sensitive.

Connect wires + to + and - to - as shown. That is, P16-1 goes to P15-6 and P16-2 goes to P15-5.

U-Control setting notes (SHADOW boilers)

NOTICE The modulating signal from U-Control P16 of one boiler to P15 of the next is polarity sensitive.

Connect wires + to + and - to - as shown. That is, P16-1 goes to P15-6 and P16-2 goes to P15-5.

- **NOTICE** Set the ADD'L HEAT DEMAND TIME to 5 minutes, or longer if possible. This is the time delay before the modulating signal will be passed on to the next boiler in series for additional space heating capacity.
- **NOTICE** Install system SUPPLY and RETURN sensors and OUTDOOR sensor for every boiler, as shown in the piping and wiring diagrams for this application. Shadow boilers will only start and stop based on their MODULATE ON or OFF DIFF. This reduces the likelihood of excessive cycling as heat demand changes.

Non-DHW SH	ADOW Boil	er U-Contro	ol settings	
		Soo other		
***	- VALUE MUST BE SET (C	DR VERIFIED) AS LISTED	boiler settings on	
D	- DEFAULT ACCEPTABLE;	CHANGE ONLY IF DESIRED	pages 48 and 51	
	BOILER SE	TTINGS		
BOILER MODEL		Verify model nu	Imber is correct	
HIGH ALTITUDE		Set to YES if	high altitude	
HIGH LIMIT		1)	
WWSD TEMP		DEFAULT (70 °F)	OR AS REQUIRED	
ADJUST OUTDOOR		DEFAULT (0 °F)	OR AS REQUIRED	
ADD'L HEAT DEMAND TYP	1	Type 4 –	SHADOW	
ADD'L HEAT DEMAND TIME		5 mii	nutes	
	SYSTEM SE	TTINGS		
	SYSTEM TYPE	Select from list	SAME AS LEAD	
BOILER PRIORITY 1	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	SAME AS LEAD SAME AS LEAD SAME AS LEAD SAME AS LEAD 5 F 10 F	
		Max On Time	D	
Space heating (any type)	TIMES	Boost Interval Prepump Time: Postpump Time:	D D D	
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF	
	MAXIMUM RATE		D	
		Calaat form lint	D	
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff		
BOILER PRIØRITY 2 Not used	TIMES	Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D D	
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D	
/ \	MAXIMUM RATE		D	
		Select from list	D	
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff		
BOILER PRIØRITY 3 Not used	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D	
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D	
/			D	
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3			
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3		D D D	



Application 18 — Multiple boilers (continued)

Multiple Ultra boilers | Multiple-zone SPACE HEATING (Circulators with WMCR) | DHW (Direct-connected)

U-Control setting notes (LAST SHADOW boiler)

NOTICE	The modulating signal from U-Control P16 of one boiler to P15 of the next is polarity sensitive.
	Connect wires $+$ to $+$ and $-$ to $-$ as shown. That is, P16–1 goes to P15–6 and P16–2 goes to P15–5.
NOTICE	The indirect water heater must be connected to the LAST boiler in the sequence. This ensures that the modulating signal from previous boilers will be passed along to the next boiler.
NOTICE	Set the last SHADOW boiler Priority 1 MAX ON TIME to 0 minutes. The boiler will im- mediately switch to DHW mode on call from the DHW aquastat. MAX ON TIME is the maximum time the boiler will continue to operate under the current PRIORITY if a lower priority is calling for heat.
NOTICE	Install system SUPPLY and RETURN sen- sors and OUTDOOR sensor for every boiler. Shadow boilers will start and stop based on their MODULATE ON or OFF DIFF. This reduces the likelihood of excessive cycling as heat demand changes.
NOTICE	Select DHW DIRECT for the DHW BOILER PRIORITY 2. This informs the control that the

DHW tank is directly connected to the boiler.

DHW SHAD	OW Boiler	U-Control	settings
D	— VALUE MUST BE SET (0 — DEFAULT ACCEPTABLE;	DR VERIFIED) AS LISTED CHANGE ONLY IF DESIRED	See other boiler settings on pages 48 and 50
BOILER SETTINGS		SET	гто
BOILER MODEL		Verify model nu	mber is correct
HIGH ALTITUDE		Set to YES if	high altitude
HIGH LIMIT)
WWSD TEMP		0	PT
ADJUST OUTDOOR		0	PT
ADD'L HEAT DEMAND TYPE		Type 4 –	SHADOW
ADD'L HEAT DEMAND TIME			D
SYSTEM SETTINGS	NEXT MENU	NEXT MENU	SET TO
	SYSTEM TYPE	Select from list	SAME AS LEAD
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	SAME AS LEAD SAME AS LEAD SAME AS LEAD SAME AS LEAD 10 F 5 F
BOILER PRIORITY 1		Max On Time	0 minutes
Space heating	TIMES	Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF
	MAXIMUM RATE		D
		Salaat from list	
	STSTEWITTE	Max Supply	
	TEMPERATURES	Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D D
<i>BOILER PRIORITY 2</i> DHW	TIMES	Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D 60 minuntes D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	ON OFF OFF
	MAXIMUM RATE		D
		Salaat from list	D
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate Of Diff Modulate Off Diff	
BOILER PRIØRITY 3 Not used	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
	MAXIMUM RATE		D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		D D D D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3		D D D



Application 19 — Multiple boilers

Multiple Ultra boilers | Multi-zone SPACE HEATING & DHW (In system) (Circulators with WMCR controllers)

Purpose

- Space heating with multiple Ultra boilers, and baseboard or fan coils, with DHW supplied by system piping.
- DHW connected to primary with a secondary connection. Multiple DHW tanks are zoned with circulators.
- DHW priority (accomplished using a SPST relay, item 42, not through the U-Control) — space heating is disabled during call for heat from water heater.

Circulators and piping

DHW

- DHW circulators supplied by installer.
- The SPST relay (item 42) set for DHW priority disables space heating as long as the U-Control Circulator 3 output is activated — the duration of this domestic priority operation is determined by the LEAD boiler's Priority 1 MAX ON TIME setting. Set this value to 60 minutes for typical application. This time can be changed to suit job requirements. OMIT relay 42 if domestic priority is not required.

BASEBOARD

- Size circulators for required flow.
- All zone circulators supplied by installer.

continued

* = Supplied by installer

- 1 DHW circulators *
- 2 BOILER circulators (shipped loose with boiler)
- 3 Zone circulators *
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- 6 Zone thermostats *
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastats *
- 10 Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- 12 Weil-McLain WMCR circulator zone controller for baseboard or fan coil zones *
- 13 Weil-McLain WMCR circulator zone controller for DHW circulators *

LEGEND

- **21** Ultra boilers
- 22 Indirect water heaters *
- 23 Flow/check valves *
- 24 Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- **26** Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- 29 Secondary piping connection for boiler loop *
- 30 Boiler relief valve (install per boiler manual)
- 40 Weil-McLain Easy-Fit headers (or field-fabricated equivalent) for connection of boiler or water heater piping to primary loop *
- 41 Distribution manifolds for piping to baseboard or fan coil zones *
- **42** SPST relay, 120 VAC coil, normally open when closed, the space heating WMCR senses the priority zone is active and will prevent other space heating zones from running until the closure on the priority zone ends









Application 19 — Multiple boilers (continued)

Multiple Ultra boilers | Multi-zone SPACE HEATING & DHW (In system) (Circulators with WMCR controllers)

BOILER

- Piping must be primary/secondary as shown, with the boiler piped in a secondary loop and the DHW piped in a secondary loop with connections spanning the boiler connections.
- See boiler manual for sizing.
- Circulator shipped loose with each boiler.

Wiring

- Connect field wiring as shown on page 52.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each - if load is higher, provide a circulator relay or contactor for circulator power.
- Provide two Weil-McLain WMCR circulator zone controllers - one for DHW circulator zoning and the other for baseboard or fan coil zoning.
- Provide SPST relay, 120 VAC coil, normally open contact if domestic priority is required. (This configuration uses the priority zone of the space heating WMCR zone controller.)

U-Control setting notes

- See the tables on pages 54 and 55 for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.
- The modulating signal from U-Control P16 of NOTICE one boiler to P15 of the next is polarity sensitive.
 - Connect wires + to + and to as shown. That is, P16-1 goes to P15-6 and P16-2 goes to P15-5.
- **DO NOT** set any boiler's PRIORITY 1 SYSTEM NOTICE TYPE to Custom or DHW-DIRECT. Shadow boilers set to TYPE 4 will not work with these settings.
 - DO NOT set the U-Controls for outdoor reset NOTICE operation. The system must provide boiler water suitable for DHW operation.
 - Install system SUPPLY and RETURN sensors for NOTICE every boiler.
 - Set the ADD'L HEAT DEMAND TIME to 5 min-NOTICE utes, or as desired. This is the time delay before the modulating signal will be passed on to the next boiler in series for additional heating capacity.
 - **DHW OPERATION** ADDITIONAL HEAT NOTICE DEMAND TIME: The additional heat demand time setting may have to be 0 minutes if the DHW demand is large compared to total boiler capacity. If the timing is too long, the boilers will not provide fast enough response.
- The MAX ON TIME setting for Priority 1 NOTICE will disable space heating for this amount of time. At the end of this time, the U-Control will switch to Priority 2

LEAD I	Boiler U-Co	ontrol setti	ngs
xxx D	VALUE MUST BE SET (OR VERIFIED) AS LISTED DEFAULT ACCEPTABLE; CHANGE ONLY IF DESIRED		See SHADOW boiler settings on pages 55
	BOILER SE	TINGS	
BOILER MODEL		Verify model nu	mber is correct
HIGH ALTITUDE		Set to YES if	high altitude
HIGH LIMIT		0)
WWSD TEMP		DEFAULT (70 °F) OR AS REQUIRED	
		DEFAULT (U°F)	
	:	5 minutes (see NC	TICE on page 54)
		J minutes (see No	THEE OF page 34)
	SYSTEM SE	TTINGS	
	SYSTEM TYPE	Select from list	DHW-SYSTEM
		Max Supply	190 F
	TEMPERATURES	Max OD Reset	D
		Min OD Reset	D
BOILER PRIORITY 1		Modulate Off Diff	D
DUW		Max On Time	60 minuntes
	TIMES	Boost Interval	D
as DHM/_SVSTEM)		Prepump Time: Postpump Time:	D
		Circulator 1	OFF
	CIRCULATORS	Circulator 2	ON
	MAXIMUM RATE	Circulator 5	D
	MINIMUM RATE		D
	SYSTEM TYPE	Select from list	FTB or FCL
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff	190 F 190 F D D
BOILER PRIORITY 2		Modulate Off Diff	
Space heating	TIMES	Boost Interval Prepump Time:	D
(Daseboard of lan coll)		Postpump Time:	D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF
	MAXIMUM RATE		D
\		Select from list	D
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff	D D D D D
<i>BOILER PRIØRITY 3</i> Not used	TIMES	Modulate Off Diff Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
	MAXIMUM RATE		D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3		D D D



Application 19 — Multiple boilers (continued)

Multiple Ultra boilers | Multi-zone SPACE HEATING & DHW (In system) (Circulators with WMCR controllers)

SHADOW Boiler U-Control settings			
D	xxx — VALUE MUST BE SET (OR VERIFIED) AS LISTED D — DEFAULT ACCEPTABLE; CHANGE ONLY IF DESIRED		See LEAD boiler settings on pages 54
	BOILER SE	TTINGS	
		Verify model nu	mber is correct
HIGH ALTITUDE		Set to YES if	high altitude
HIGH LIMIT		[)
WWSD TEMP		0	PT
ADJUST OUTDOOR		Орт	
ADD'L HEAT DEMAND TYPE		Type 4 – SHADOW	
ADD'L HEAT DEMAND TIME		5 minutes (see NC	DTICE on page 54)
	SYSTEM SE	TTINGS	
	SYSTEM TYPE	Select from list	FTB or FCL
ρημ ερ οριαρίτν 1	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	190 F D D D D D
Space beating	TIMES	Max On Time	D
(baseboard or fan coil)		Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF
	MAXIMUM RATE		D
		Select from list	D
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D D D D
BOILER PRIØRITY 2 Not used	TIMES	Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
/	MAXIMUM RATE		D
<u> </u>	SYSTEM TYPE	Select from list	D
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	
<i>BOILER PRIØRITY 3</i> Not used	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
/			D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		D D D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3		D D D



Application 20 — Multiple boilers

Multiple Ultra boilers | Multiple loads on SECONDARY loops | DHW (Direct-connected)

Purpose

- Space heating with multiple Ultra boilers, with multiple-zone baseboard space heating.
- DHW piped directly to one boiler.
- DHW priority space heating and heater exchanger heating are disabled during call for heat from water heater.

Circulators and piping

PRIMARY PIPING

- Provides crossover-style connection for multiple subsystems. Each subsystem connects via a secondary loop take-off.
- Size circulator for required flow primary (system) circulator supplied by installer.

SUBSYSTEMS

- Subsystem supply/return piping must be connected to crossover bridges with secondary connections spaced apart as shown.
- Subsystems can use any means desired, such as baseboard, cast iron radiators, fan coils, heat exchanger or radiant.
- Provide controls and components needed for zoning (as shown in typical subsystem example).

* = Supplied by installer

- 1 DHW circulator *
- 2 BOILER circulators (shipped loose with boiler)
 - System circulator *
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control

3

- 6 Zone thermostats, typical
- 7 Supply temperature sensor strap to supply
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- 12 Typical Weil-McLain WMCR circulator zone controller for baseboard or fan coil zones *
- 16 Baseboard zone circulators *
- 21 Ultra boilers

LEGEND

- 22 Indirect water heater *
- 23 Flow/check valves *
- 24 Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- 26 Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- 29 Secondary piping connection for boiler loop *
- 30 Boiler relief valve (install per boiler manual)
- **40** Weil-McLain Easy-Fit headers (or fieldfabricated equivalent) for connection of boiler or water heater piping to primary loop *
- 41 Distribution manifolds for piping to baseboard or fan coil zones *
- 43 Balancing valves *
- 45 Secondary connections to heating subsystems *





PIPING

Piping overview

- Piping uses a crossover bridge for each subsystem. The subsystem supply and return pipes must be connected using a secondary connection from the bridge as shown.
- Use the balancing valves in the crossover bridge lines to balance flow as needed.
- A typical subsystem comprised of baseboard heating zones with zone circulators is illustrated. The wiring diagram on the opposite page shows the circulator zoning panel for this subsystem.
- Other subsystems could provide heat for radiant heating, fan coil units, pool heat exchangers, etc.
- Domestic hot water is supplied by an indirect water heater piped to the last boiler in the LEAD/SHADOW sequence. When the DHW aquastat calls for heat, the boiler circulator turns off and the DHW circulator turns on. Other boilers continue to provide heat to the system.
- The major advantage to the two-pipe primary/secondary method shown here is that all subsystems receive supply water at the same temperature. Temperature can then be regulated in the subsystem as needed. In contrast, a one-pipe primary/secondary system loses temperature as heat is extracted by subsystems around its perimeter.

MINIMUM Boiler loop pipe siz

Ultra-155, 230 11/4"

1^

1½″

Ultra-80, 105

Ultra-299, 399

(5)

-21

Boiler 1





Application 20 — Multiple boilers (continued)

Multiple Ultra boilers | Multiple loads on SECONDARY loops | DHW (Direct-connected)

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping — see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently — see boiler manual and other applications in this guide.
- Pipe the indirect water heater to the last SHADOW boiler. The U-Control on the last SHADOW boiler is set to immediately switch to DHW heating on call from the DHW aquastat. Set system type to DHW-DIRECT.

BOILER

- Ultra boiler piping must be primary/secondary as shown, with the boiler piped in a secondary loop and the DHW piped to the last SHADOW boiler.
- See boiler manual for sizing.
- Circulator shipped loose with boiler.

Wiring

NOTICE

NOTICE

- Connect field wiring as shown on page 56.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each if load is higher, provide a circulator relay or contactor for circulator power.
- Provide all piping and controls needed for each subsystem connected.

U-Control setting notes

- See the tables on pages 58 and 59 for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.
 - **NOTICE**The modulating signal from U-Control P16 of
one boiler to P15 of the next is polarity sensitive.
Connect wires + to + and to as shown. That
is, P16-1 goes to P15-6 and P16-2 goes to P15-5.





LAST SHADOW boiler only — Select DHW DIRECT for the DHW BOILER PRIORITY 2. This informs the control that the DHW tank is directly connected to the boiler

NOTICE Install system SUPPLY and RETURN sensors and OUTDOOR sensor for every boiler, as shown in the piping and wiring diagrams for this application. Shadow boilers will only start and stop based on their MODULATE ON or OFF DIFF. This reduces the likelihood of excessive cycling as heat demand changes.

NOTICE Set the last SHADOW boiler MAX ON TIME to 0 minutes. The boiler will immediately switch to DHW mode on call from the DHW aquastat.

LEAD I	Boiler U-Co	ontrol setti	ngs
XXX	- VALUE MUST BE SET (C	R VERIFIED) AS LISTED	See SHADOW
D	- DEFAULT ACCEPTABLE;	CHANGE ONLY IF DESIRED	boiler settings on page 59
	BOILER SET	TTINGS	
		Varify model pu	mbor is correct
		Set to VES if	high altitude
		Set to TES II	
		D===== (70 °E)	
		DEFAULT (70 °F) OR AS REQUIRED	
ADJUST OUTDOOR		DEFAULT (U °F) OR AS REQUIRED	
ADD'L HEAT DEMAND TYPE		Type 3 – LEAD	
ADD'L HEAT DEMAND TIME		5 mir	nutes
	SYSTEM SE	TTINGS	
	SYSTEM TYPE	Select from list	Select
BOILER PRIORITY 1	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	180 F D (70F) or as regin D (0F) or as reguined D or as required D D
Select system		Max On Time	D
type most rep-		B	
resentative of	TIMES	Boost Interval Prepump Time:	D
subsystems con-		Postpump Time:	D
nected	CIRCULATORS	Circulator 1 Circulator 2	OFF ON
		Circulator 3	ON
			D
		Select from list	
\backslash /	STOTEMTIFE	Max Supply	D
\backslash		Min Supply	D
	TEMPERATURES	Max OD Reset	D
		Modulate On Diff	D
		Modulate Off Diff	D
BUILER PRIVRI I T Z		Max On Time	
	TIMES	Boost Interval	D
Not used		Prepump Time:	D
		Postpump Time:	D
	CIRCULATORS	Circulator 1 Circulator 2	D
		Circulator 3	D
	MAXIMUM RATE		D
<u> </u>	MINIMUM RATE		D
\backslash /	SYSTEMTYPE	Select from list	D
\backslash /		Min Supply	D
	TEMPERATURES	Max OD Reset	D
		MIN OD Reset Modulate On Diff	D
		Modulate Off Diff	D
BOILER PRIØRITY 3			
X	TIMES	Min On Lime Boost Interval	D
Not used \		Prepump Time:	D
		Postpump Time:	D
	CIRCULATORS	Circulator 1 Circulator 2	D D
		Circulator 3	D
/ \	MAXIMUM RATE		D
	MINIMUM RATE		D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		D D D
	Circulator 1		D
FREEZE PROTECT CIRCS	Circulator 2 Circulator 3		D D



Application 20 — Multiple boilers (continued)

Multiple Ultra boilers | Multiple loads on SECONDARY loops | DHW (Direct-connected)

Non-DHW SH	ADOW Boil	er U-Contr	ol settings
xxx D	 VALUE MUST BE SET (OR VERIFIED) AS LISTED DEFAULT ACCEPTABLE; CHANGE ONLY IF DESIRED 		See LEAD boiler settings on page 58
		TTINGS	
	BOILER SE	TINGS	
BOILER MODEL		Verify model n	umber is correct
HIGH ALTITUDE		Set to YES if	high altitude
HIGH LIMIT			D
WWSD TEMP		0)PT
ADJUST OUTDOOR	-	Turne A	
		Type 4 –	
			nuces
	SYSTEM SE	ITINGS	
	SYSTEM TYPE	Select from list Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	SAME AS LEAD SAME AS LEAD SAME AS LEAD SAME AS LEAD SAME AS LEAD 5 F 10 F
BOILER PRIORITY 1		Max On Time	D
Space heating	TIMES	Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF
	MAXIMUM RATE		D
\setminus		Select from list	D
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D D D D
<i>BOILER PRIØRITY 2</i> Not used	TIMES	Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
/			D
(SYSTEM TYPE	Select from list	D
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D D
<i>BOILER PRIØRITY 3</i> Not used	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
	MAXIMUM RATE		D
/	MINIMUM RATE		D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		DDD
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3		D D D

DHW SHAD	OW Boiler	U-Control	settings
xxx D	 VALUE MUST BE SET (OR VERIFIED) AS LISTED DEFAULT ACCEPTABLE; CHANGE ONLY IF DESIRED 		See LEAD boiler settings on page 58
	BOILER SE	TTINGS	
		Verify model nu	Imper is correct
		Set to YES IT	nign altitude
WWSD TEMP		Орт	
ADJUST OUTDOOR		Орт	
ADD'L HEAT DEMAND TYPE		Type 4 – SHADOW	
ADD'L HEAT DEMAND TIME)
s	SYSTEM SE	TTINGS	
	SYSTEM TYPE	Select from list	
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	SAME AS LEAD SAME AS LEAD SAME AS LEAD SAME AS LEAD 10 F 5 F
BOILER PRIORITY 1		Max On Time	0 minutes
Space heating	TIMES	Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF
	MAXIMUM RATE		D
	SYSTEM TYPE	Select from list	D DHW-DIRECT
	TEMPERATURES	Max Supply Max OD Reset Min OD Reset Modulate On Diff	190 F
<i>boiler priority 2</i> Dhw	TIMES	Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D 60 minuntes D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	ON OFF OFF
	MAXIMUM RATE		D
		Select from list	0
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff	D D D D D D
<i>BOILER PRIØRITY 3</i> Not used	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
/			D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		D D D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3		D D D



Application 21 — Multiple boilers

BASE LOADING with ULTRA boilers | DHW (Direct connected)

Purpose

On an existing or new installation, provide base loading with high-efficiency Ultra boilers.

- Use a large boiler only as needed, such as during high heat demand periods (low outdoor temperature periods).
- The WMR-21 relay, SPST relay and outdoor temperature control shown in this application automatically enable or disable the large boiler at outdoor temperatures above the outdoor temperature control setting, the large boiler is not enabled. At colder outdoor temperatures, when the load is higher, the large boiler is enabled.
- An alternate method is to use a MOD-CON-CNC controller. This device provides automatic switching of base load boilers based on outdoor temperature and also provides boiler sequencing.

The recommended temperature settings in this application are based on typical baseboard, radiator or fan coil systems. For radiant systems or any other lower temperature installation, set the U-Control and system aquastat temperatures as needed.

NOTICE DO NOT set the system aquastat (item 46) higher than 180°F. The Ultra boilers will lockout if temperature exceeds 190°F. Set the Ultra LEAD boiler Priority 1 MAX SUPPLY temperature 20°F lower than the system aquastat setting.

DHW is piped directly to one of the Ultra base load boilers. If additional DHW capacity is required, pipe the DHW units in a secondary loop as in Application 19 — Multiple boilers, page 52. DHW priority — space heating is disabled on the DHW boiler during call for heat from the water heater.

continued

FIELD WIRING eld wiring to culators DHW AQUASTAT SYSTEM THERMOSTAT (2) P15 BOILER 4 8 SUPPL 15 1 2 3 2 1 WMR-21 Last (11 DHW 10 . 2 BRETURN SHADOW Boiler P10 Black 2-pole Remove factory jumper on terminals L1 to 3. SHADOW Boiler(s) + Com 13456 Ground PIG Groundo 6 5 Field wiring to circulators -Neutralo 120 VAC Hoto Red 6-pole (7) 6 (47) (8) 2 ·Com-P2 OUTDOOR Black 9-pole TEMP CTRL 3 BOILER 00 (10) P12 OUTDOOR Field wiring to circulators and relay output (0 - 10 VDC) **LEAD Boiler** 23456 Red 6-pole (3) 010 7 6 5 4 3 2 1 SYSTEM \Rightarrow SUPPLY 10 2 (7) (5) Large boiler S-pol-(8) thermostat BOILER • RETURN input termi P2 Control 4 Black 8 SYSTEM P10 Black 11 P12 OUTDOOR (10) (13) SPST Relay

* = Supplied by installer

- 1 DHW circulator *
- 2 Ultra BOILER circulators (shipped loose with boiler)
- 3 System circulator (typical in-line pump shown)*
- 4 120VAC power supply, 15-amp minimum rating
- 5 U-Control
- 7 Supply temperature sensor strap to supply line
- 8 Return temperature sensor strap to return line
- 9 DHW tank aquastat *
- 10 Outdoor temperature sensor (supplied with boiler; install if U-Control will be set for outdoor reset operation)
- 11 Low water cutoff (if used) *
- 13 Relay, 120 VAC coil, SPST *
- 15 Weil-McLain WMR-21 relay
- 21 Ultra boilers
- 22 Indirect water heater *
- 23 Flow/check valves *

LEGEND

- 24 Air separator with automatic air vent *
- 25 Diaphragm-type expansion tank *
- 26 Fresh water supply install per applicable codes *
- 27 Isolation valves *
- 28 Purge/drain valves *
- 29 Secondary piping connection for boiler loop *
- **30** Boiler relief valve (install per boiler manual)
- **40** Weil-McLain Easy-Fit headers (or fieldfabricated equivalent) for connection of Ultra boiler piping to primary loop *
- 45 Large boiler, either existing or new installation — typically a commercial-sized forced draft boiler on existing installations — can be one or more forced draft boilers or one or more Ultra Commercial boilers for new or boiler replacement installations
- 46 System aquastat See NOTICE at left
- **47** Outdoor temperature control (Honeywell T6031A or equivalent) break on rise to shut off large boiler(s) above the outdoor control setpoint (typically between 40°F and 50°F)
- **46** System thermostat or system heat demand contact



- For best results in heating response, and to avoid excessive cycling in changeover between boilers, size the Ultra boiler total input to at least the minimum input of the large boiler.
- If adding Ultra boilers for base loading with an existing large boiler, consider replacing the forced draft burner with a hi-lo or modulating burner. This will provide a turndown in boiler firing rate and reduce the recommended input for the base load boilers. It will also improve the large boiler's efficiency since the combustion efficiency will usually increase noticeably at low fire.

Piping overview

- This example can apply to an existing large boiler, such as a commercial-sized forced draft cast iron sectional boiler like the Weil-McLain 80 or 88 series.
- For a new system installation, you could use one or more Ultra Commercial boilers for the large boiler, with one or more Ultra Residential boilers for the base load units.
- The piping is shown with a conventional direct-connected system. The preferred method would be to pipe the large boiler(s) on a secondary loop as shown in the inset, upper right. The Ultra Residential boilers must be piped on a secondary loop as shown above.
- The indirect water heater is connected to one of the Ultra boilers, ensuring that DHW generation always takes advantage of the Ultra boiler's high efficiency.
- For each Ultra boiler, strap a supply sensor and return sensor to the system piping as shown.

H



Application 21 — Multiple boilers (continued)

BASE LOADING with ULTRA boilers | DHW (Direct connected)

SYSTEM PIPING

- Size system circulator for required flow system circulator supplied by installer.
- Piping shown in this example is direct-connected, and is acceptable for an existing installation, but primary/secondary piping is preferred. For boiler replacement and new installations, use a secondary circuit for the large boiler(s) as shown in the piping diagram inset.

DHW

- DHW circulator must be selected to handle the pressure drop through the Ultra boiler, water heater and piping see boiler manual for recommended sizing. DHW circulator supplied by installer.
- For some large indirect water heaters, the required flow rate may require piping the water heater differently see boiler manual and other applications in this guide.
- Pipe the indirect water heater to the last SHADOW boiler. The U-Control on the last SHADOW boiler is set to immediately switch to DHW heating on call from the DHW aquastat. Set system type to DHW-DIRECT.

BOILER

- Ultra boiler piping must be primary/secondary as shown, with the boiler piped in a secondary loop and the DHW piped to the last SHADOW boiler.
- See boiler manual for sizing piping.
- Circulator shipped loose with boiler.

Wiring

- Connect field wiring as shown on page 60.
- For circulators connected to the U-Control, the maximum circulator load is 2.2 amps each if load is higher, provide a circulator relay or contactor for circulator power.
- Provide and install a WMR-21 relay, a SPST relay with 120 VAC coil and an outdoor temperature control (Honeywell T6031A or equivalent). Set the outdoor temperature control between 40°F and 50°F for most installations. Mount the sensing bulb outside using an outdoor shield. Locate the bulb away from direct sunlight and in a location not subject to snow, ice or debris accumulation.

U-Control setting notes

- See the tables on pages 62 and 63 for required and optional settings.
- To see the navigation sequence to access the BOILER SETTINGS and SYSTEM SETTINGS menus, see page 7.



LEAD I	Boiler U-Co	ontrol setti	ngs
xxx D	— VALUE MUST BE SET (— DEFAULT ACCEPTABLE;	See SHADOW boiler settings on page 59	
	BOILER SE	TTINGS	
	BOILER JE	i i ində	
BOILER MODEL		Verify model nu	mber is correct
HIGH ALTITUDE		Set to YES if	high altitude
HIGH LIMIT)
		DEFAULT (70 °E)	
			OR AS REQUIRED
		DEFAULT (U F)	OR AS REQUIRED
ADD'L HEAT DEMAND TYPE	:	Type 3	- LEAD
ADD'L HEAT DEMAND TIME		5 mir	nutes
	SYSTEM SE	TTINGS	
	SVSTEM TVDE	Salaat from list	Soloot
	STSTEWITTE	Max Supply	
DOULED DDIODITY 4		Min Supply	140 F
BUILER PRIURI I T	TEMPERATURES	Max OD Reset	70 F
		Min OD Reset	0 F
Large boiler		Modulate Off Diff	D
enabled		Max On Time	15 minutes
			To minutoo
Select system type	TIMES	Boost Interval	D
most representa-		Prepump Time: Postnumn Time:	D
tive of subsystems		Circulator 1	ON
live of subsystems	CIRCULATORS	Circulator 2	ON
connected		Circulator 3	ON
	MAXIMUM RATE		D
			D
	SYSTEMTYPE	Select from list	Select
		Max Supply Min Supply	190 F 70 F
BUILER PRIURITY 2	TEMDEDATIIDES	Max OD Reset	70 F
		Min OD Reset	0 F
Large boiler		Modulate Off Diff	D
NOT enabled		Max On Time	15 minutes
		Min On Time	D
Select system type	TIMES	Boost Interval	D
most representa-		Postpump Time:	D
tive of subsystems		Circulator 1	OFF
connected	CIRCULATORS	Circulator 2	ON
		Circulator 5	
			D
\/	SYSTEM TYPE	Select from list	D
\backslash /		Max Supply	D
\backslash		Min Supply	D
	TEMPERATURES	Max OD Reset	D
		Min OD Reset Modulate On Diff	D
		Modulate Off Diff	D
BUILER PRIVRITY 3			
X	TIMES	Min On Time Boost Interval	D
Not used	TIMES	Prepump Time:	D
		Postpump Time:	D
		Circulator 1	D
	GIRCULATORS	Circulator 2 Circulator 3	
	MAXIMUM RATE		D
/ \	MINIMUM RATE		D
· · · · · · · · · · · · · · · · · · ·	Circulator 1		D
CIRCULATOR EXERCISING	Circulator 2		D
	Circulator 3		D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2		D
	Circulator 3		D



Application 21 — Multiple boilers (continued)

BASE LOADING with ULTRA boilers | DHW (Direct connected)

Non-DHW SH	ADOW BOII	er U-Contr	ol settings
xxx D	— VALUE MUST BE SET (— DEFAULT ACCEPTABLE	OR VERIFIED) AS LISTED	See LEAD boiler settings on page 58
			13
	BOILER SE	TTINGS	
BOILER MODEL		Verify model n	umber is correct
HIGH ALTITUDE		Set to YES if	high altitude
HIGH LIMIT			D
WWSD TEMP		C	РТ
ADJUST OUTDOOR		C	PT
ADD'L HEAT DEMAND TYP	E	Type 4 –	SHADOW
ADD'L HEAT DEMAND TIME		5 mi	nutes
	SYSTEM SE	TTINGS	
	SYSTEM TYPE	Select from list	SAME AS LEAD
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	190 F 70 F 70 F 0 F 5 F 10 F
BOILER PRIORITY 1		Max On Time	D
Space heating	TIMES	Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF
	MAXIMUM RATE		D
\		Select from list	D
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D D D D
<i>BOILER PRIØRITY 2</i> Not used	TIMES	Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
	MAXIMUM RATE		D
<		Select from list	D
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff	D D D D D
BOILER PRIØRITY 3 Not used	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
/			D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		D D D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3		D D D

DHW SHAD	OW Boiler	U-Control	settings
D xxx	- VALUE MUST BE SET (OR VERIFIED) AS LISTED - DEFAULT ACCEPTABLE; CHANGE ONLY IF DESIRED		See LEAD boiler settings on page 58
	BOILER SE	TTINGS	
		Verify model n	umber is correct
		Set to VES if	high altitude
HIGH LIMIT		Set to TES II	
WWSD TEMP		0	PT
ADJUST OUTDOOR		C	PT
ADD'L HEAT DEMAND TYPE	[Type 4 –	SHADOW
ADD'L HEAT DEMAND TIME			D
9	SYSTEM SE	ETTINGS	
	SYSTEM TYPE	Select from list	SAME AS LEAD
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	SAME AS LEAD SAME AS LEAD SAME AS LEAD SAME AS LEAD 10 F 5 F
BOILER PRIORITY 1		Max On Time	0 minutes
Space heating	TIMES	Boost Interval Prepump Time: Postpump Time:	D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	OFF ON OFF
			D
	SYSTEM TYPE	Select from list	DHW-DIRECT
	TEMPERATURES	Max Supply Max OD Reset Min OD Reset Modulate On Diff	190 F D D D
<i>Boiler Priority 2</i> Dhw	TIMES	Max On Time Min On Time Boost Interval Prepump Time: Postpump Time:	D 60 minuntes D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	ON OFF OFF
	MAXIMUM RATE		D
		Salact from list	D
	TEMPERATURES	Max Supply Min Supply Max OD Reset Min OD Reset Modulate On Diff Modulate Off Diff	D D D D D D D
<i>BOILER PRIØRITY 3</i> Not used	TIMES	Min On Time Boost Interval Prepump Time: Postpump Time:	D D D D
	CIRCULATORS	Circulator 1 Circulator 2 Circulator 3	D D D
$ / \qquad \setminus$			D
CIRCULATOR EXERCISING	Circulator 1 Circulator 2 Circulator 3		D D D
FREEZE PROTECT CIRCS	Circulator 1 Circulator 2 Circulator 3		D D D

Appendix A

OUTDOOR RESET Settings and Troubleshooting

Outdoor reset control settings

- **NOTICE** Outdoor reset can improve comfort and operating efficiency, making the best possible use of the Ultra boiler's condensing ability. Improperly setting outdoor reset settings in the U-Control can result in insufficient heat. Factory default settings for the U-Control will work in many instances, but not all. Use the information below to set the control to meet the installation conditions.
- 1. Outdoor reset tries to match heat input to the system heat loss. As outdoor temperature rises (heat loss decreases), the U-Control reduces the supply water temperature to the system, thus reducing heat input.
- 2. Setup desired settings for each of the priorities used
- 3. **MIN and MAX SUPPLY temperatures** For an explanation of the target temperatures and associated outdoor temperatures, see Figure 1.
 - a. **MAX OD RESET** means the outdoor temperature at which the target temperature reaches its maximum value (MAX SUPPLY). In the example of Figure 1, this occurs at 0°F outside (the factory default setting).

MAX OD RESET should equal the **ODT** (outdoor design temperature) for the installation's location.

- MAX SUPPLY should equal the required supply water temperature for the system at design maximum heat loss (typically 180°F for finned tube baseboard on new installations).
- c. **MIN OD RESET** means the outdoor temperature at which the target temperature reaches its minimum (MIN SUPPLY). In the example of Figure 1, this occurs at 70 °F (the factory default).
- d. **MIN SUPPLY** should equal the desired minimum supply water temperature for the system. The factory default is 130°F. This could be set as low as 70°F, which would supply "zero heat" when outdoor temperature is 70°F, because supply water temp would equal room temp. See examples in Figure 1.
- e. Note that the reset lines are curved. The shape of this curve is matched (characterized) to the response of the system type chosen. This ensures the most effective reset operation.
- 4. **Modulate on differential** The temperature must drop this many degrees below target temperature for the boiler to come on.
- 5. **Modulate off differential** While the boiler is firing, as the temperature increases above the target temperature, the boiler firing rate is reduced. At this many degrees above the target temperature, the boiler shuts down.
- 6. **Boost interval** This adjustment is located in the TIMES menus. The boost timer starts on a call for heat. If the boost interval time passes and the call for heat is still on, the U-Control "boosts" the supply water temperature setpoint by 10°F. This occurs again if another boost interval elapses. Boost will continue until the setpoint reaches the MAX SUPPLY setting. The purpose of boost is to compensate for changes in demand not addressed by the reset curve. Typically, set boost to 30 minutes. The factory default is "OFF" — that is, boost is not enabled with default settings.

Troubleshooting insufficient heat calls

- 1. Insufficient heat can occur if the supply water temperature to the heating units is not hot enough. Possibly reasons are:
 - a. The factory default settings for outdoor reset are not a good match to the system needs.
 - b. The baseboard may have been sized for higher water supply temperature. Older systems were often sized for baseboard supply temperature of 210°F (average water temperature of 200°F).
 - c. See additional potential causes in the NOTICE below.



- One way to check whether water supply temperature is the problem is to measure the water temperature going to the heating units. Then see if this is reasonable by:
 - a. Look up the heating unit output rating at 190°F.
 - b. Look up the heating unit output rating at the water temperature you measured.
 - c. Measure the current outside temperature.
 - d. Look up the ODT (outdoor design temperature) for the area.
 - e. At this outside temperature, the heating unit output should be about equal to:
 - $Output = (output at 190^{\circ}F) x (70 outside temp)/(70 ODT)$
- 3. Make sure the outdoor sensor is properly shielded so it isn't heating up due to solar gain. To verify, measure outside temperature and compare to the value shown on the U-Control display. If the sensor is shielded and still reading incorrectly, change the ADJUST OUTDOOR setting in the Boiler Settings menu.
- In the event of an insufficient heat call, make the following adjustments to ensure the U-Control is delivering the best possible performance for the application.
 - a. **MAX OD RESET** Set to a value of ODT (outdoor design temp for the location) PLUS 15°F. (Example: for an ODT of 10°F, set to $10^{\circ} + 15^{\circ} = 25^{\circ}F.$)
 - b. **MAX SUPPLY** Set to 190°F. (Exception: For radiant systems, set to design operating temperature at maximum heat load.)
 - c. **MIN OD RESET** Set to 70°F (factory default).
 - d. **MIN SUPPLY** Set to 70°F (increase value to 130°F if the problem persists).
 - e. BOOST INTERVAL Set to 30 minutes.



If the insufficient heat issue persists after making the adjustments recommended here, look for other possible causes, such as:

If the problem only occurs in some areas of the home, the heating units there may be undersized, or the problem area may not have control over boiler operation. Additional heating units or a zoning change may correct the problem. Other issues, such as air in the system, poor flow distribution or too little flow can also cause insufficient heat.



M



U**M**





Weil-McLain 500 Blaine Street Michigan City, IN 46360-2388 http://www.weil-mclain.com

M